

Operation Manual

41D+42D Series – Rev 1.1

P/N 160907-10

41D+42D Series Programmable DC Load



TM

ADAPTIVE Power Systems

Worldwide Supplier of Power Equipment

Copyright © 2014, Adaptive Power Systems, Inc. (APS) • All Rights Reserved • No reproduction without written authorization from APS.

PAGE LEFT INTENTIONALLY LEFT BLANK FOR HARDCOPY VERSIONS OF THIS DOCUMENT



Table of Contents

1	Contact Information	8
2	Front Matter.....	9
2.1	Limited Warranty	9
2.2	Service and Spare Parts Limited Warranty	9
2.3	Safety Information.....	9
2.4	Safety Notices	11
3	Product Overview	13
3.1	General Description.....	13
3.2	Operating Modes	13
3.2.1	Constant Current Mode	14
3.2.2	Constant Resistance Mode	14
3.2.3	Constant Voltage Mode	14
3.2.4	Constant Power Mode	15
3.2.5	LED Mode.....	15
3.3	Static versus Dynamic Operating Modes	16
3.3.1	Programmable Parameters.....	16
3.3.2	Slew Rates	17
3.3.3	Determining Actual Transition Times	18
3.4	Current Read-back.....	19
3.5	Product Features	20
3.6	Accessories Included	21
3.6.1	Accessory Installation	22
3.7	Interface Options.....	23
4	Technical Specifications	24
4.1	Operating Ranges	24
4.2	Operating Modes	24
4.3	Protection Modes.....	25
4.4	Dynamic Operation Mode	25
4.5	Metering	25
4.6	PWM Dimming Controls.....	26
4.7	Shorting Relay (Option).....	26
4.8	AC Input & Cooling	26
4.9	Dimensions & Weight	26
4.10	Environmental	26
4.11	Voltage versus Current Operating Envelope Charts.....	27
4.11.1	Model 41D3002 V-I Curves	28
4.11.2	Model 41D1020 V-I Curves	29
4.11.3	Model 41D5002 V-I Curves	30
4.11.4	Model 42D5003 V-I Curves	31
5	Unpacking and Installation	32
5.1	Inspection	32
5.2	Load Module Installation and Removal in Mainframe.....	32
5.2.1	Module Removal	32
5.2.2	Module Installation	33
5.3	Cleaning.....	34
5.4	Powering Up	34

5.5	In Case of Malfunction	34
5.6	Load Connections	35
5.7	Analog Programming Input.....	36
5.8	Load Current Slew Rate.....	37
6	Front Panel Operation	39
6.1	Front Panel Layout	39
6.2	41D Series User Controls and Readouts.....	40
6.3	42D Series User Controls and Readouts.....	66
6.4	Operating Flowchart for 41D+42D Series Load Modules.....	68
6.5	Go/NoGo LIMIT Testing	69
6.5.1	Limits	69
6.5.2	Go/NoGo Testing in CC Mode.....	69
6.5.3	Go/NoGo Testing in CC Dynamic Mode	70
6.5.4	Go/NoGo Testing in CR Mode.....	70
6.5.5	Go/NoGo Testing in CV Mode	71
6.5.6	Go/NoGo Testing in CP Mode.....	71
6.6	Initial Power-on Settings	72
6.6.1	Model 41D3002 Initial Settings.....	72
6.6.2	Model 41D1020 Initial Settings.....	72
6.6.3	Model 41D5002 Initial Settings.....	73
6.6.4	Model 42D5003 Initial Settings.....	73
7	Load Connections, Applications and Protection Features	74
7.1	INPUT Terminals	74
7.1.1	Banana Jack Connectors.....	74
7.1.2	Y-hook / Spade Lug Terminals.....	74
7.1.3	Lead Wire Insertion	74
7.1.4	Banana Jack Connector and Spade Lug Terminals.....	74
7.1.5	Plug Connector and Lead Wire Insertion	75
7.2	Wire Size	75
7.2.1	Wire Size Guidelines	75
7.3	Connecting a UUT.....	76
7.4	Polarity and Ground – Multiple Output Power Supplies.....	77
7.5	Voltage Sense Input Terminals	78
7.6	Current Output Monitor (I-Monitor).....	79
7.6.1	Non-Isolated Output	79
7.6.2	Output Impedance	80
7.6.3	Connecting I-Monitor Output to an Oscilloscope.....	81
7.7	Parallel Operation.....	82
7.7.1	Parallel Mode Connection.....	82
7.7.2	Allowable Operating Modes	82
7.7.3	Exceptions	82
7.8	Series Operation	82
7.9	Zero-Voltage Loading	83
7.10	Protection Features.....	84
7.10.1	Over Voltage Protection.....	84
7.10.2	Over Current Protection.....	84
7.10.3	Over Power Protection.....	84
7.10.4	Over Temperature Protection	85
7.10.5	Reverse Polarity Protection Indication	85

8	LED Mod Application Examples	86
8.1	Overview	86
8.2	LED Characteristics	86
8.2.1	Definitions	86
8.2.2	LED Operation	87
8.3	Multiple LED Configurations	88
8.3.1	Series or Cascading Mode	88
8.3.2	Parallel Mode	89
8.4	LED Mode Settings	89
8.4.1	LED No. Setting	90
8.4.2	LED Vd Setting	90
8.4.3	LED Rd Setting	90
8.4.4	Impact of Changing Vd and Rd on Voltage and Current	91
8.4.5	LED Vo Setting	91
8.4.6	LED Io Setting	91
8.4.7	LED Rr Settings	92
9	Auto Sequence Programming Examples	93
9.1	Overview	93
9.2	Edit Mode	93
9.3	Test Mode	94
9.4	AUTO TEST SEQUENCE Example	95
10	Short Circuit, OPP and OCP Test Examples	97
10.1	Overview	97
10.2	SHORT Test	98
10.2.1	External SHORT RELAY Based Test	99
10.2.2	SHORT Relay Test Procedure	99
10.2.3	Remote SHORT Programming Commands	101
10.3	OPP Test	101
10.4	OCP Test	102
11	Remote Control Programming	103
11.1	Overview	103
12	Calibration	104
12.1	Overview	104
12.2	Calibration Interval	104
12.3	Calibration Coefficients	104
12.4	Calibration Procedures	104
13	CE MARK Declaration of Conformity	105
14	RoHS Material Content Declaration	106
	Index	107

Table of Tables

Table 3-1: Dynamic Current Mode Parameters.....	16
Table 3-2: Included Accessories	21
Table 6-1: Front Panel Display and Keyboard Functions	65
Table 6-2: Keyboard Layout Cross Reference between 42D and 41D LED Load Modules	67
Table 6-3: Model 41D3002 Power-on Settings.....	72
Table 6-4: Model 41D1020 Power-on Settings.....	72
Table 6-5: Model 41D5002 Power-on Settings.....	73
Table 6-6: Model 42D5003 Power-on Settings.....	73
Table 7-1: Load Wire Size Table.....	75
Table 7-2: Multiple Output DC Supply Polarity Connection	77
Table 9-1: Auto-Test Sequence Example Values	95

Table of Figures

Figure 3-1: Dynamic Current Wave Form	16
Figure 3-2: Rise Time Performance Limits	17
Figure 3-3: 41D+42D Series Accessories.....	21
Figure 3-4: Load and sense connections using Y-hooks/spade lugs	22
Figure 3-5: Load and sense connections using banana plugs - insertion	22
Figure 3-6: Load and sense connections using banana plugs - inserted	23
Figure 5-1: Load Module Removal.....	33
Figure 5-2: Location and Pin-out of Analog Programming Input Connector	36
Figure 5-3: Channel Positions for Analog Input Identification.....	36
Figure 5-4: Analog Programming Example	37
Figure 5-5: Effect of Current Slew Rate Settings on Power Supply Testing	38
Figure 6-1: 44M04 Chassis with 41L0630 Series Loads Front Panel View	39
Figure 6-2: Front Panel User Controls and Indicators	40
Figure 6-3: Front Panel User Controls and Indicators	66
Figure 6-4: Operation Flow Chart - 41D+42D Series Load Module	68
Figure 6-5: LIMIT Test in CC Mode.....	69
Figure 6-6: LIMIT Test in Dynamic CC Mode.....	70
Figure 6-7: LIMIT Test in CR Mode	70
Figure 6-8: LIMIT Test in CV Mode	71
Figure 6-9: LIMIT Test in CP Mode.....	71
Figure 7-1: Doubling wire size using spade lugs	75
Figure 7-2: DC Load Connection with Internal Voltage Sense	78
Figure 7-3: DC Load Connection with External Voltage Sense	78
Figure 7-4: Equivalent I-Monitor Output Circuit	80
Figure 7-5: Correct I-Monitor Connections to UUT and Oscilloscope	81
Figure 7-6: Incorrect I-Monitor Connections to UUT and Oscilloscope.....	81
Figure 7-7: Parallel Load Connection.....	82
Figure 7-8: Zero Volt Load Connection.....	83
Figure 8-1: LED Equivalent Circuit Diagram.....	86
Figure 8-2: LED Voltage and Current Waveforms.....	87
Figure 8-3: Series or Cascading LED Configuration	88
Figure 8-4: Parallel LED String Configuration.....	89
Figure 8-5: Typical LED Vd Values by LED Type	90
Figure 8-6: LED Vd and Rd Based Load Curve	91
Figure 8-7: LED Based Load Curve Effects	91
Figure 8-8: Enhanced LED V-I Curve Model.....	92
Figure 9-1: Auto-Test Sequence Example Illustration	95
Figure 10-1: Built-in Test Modes - Flow Chart OCP, OPP, SHORRT	97
Figure 10-2: External SHORT Relay Test Setup	99

1 Contact Information

AMERICA / CANADA

Adaptive Power Systems
Irvine, USA
Phone: +1(949) 752-8400
Fax: +1 (949) 756-0838
Email: support@adaptivepower.com

EUROPE

Caltest Instruments Ltd.
Guildford, United Kingdom
Phone: +44(0)1483 302 700
Fax: +44(0)1483 300 562
Email: support@adaptivepower.com

CHINA

PPST Shanghai Co. Ltd.
Shanghai, China
Phone: +86-21-6763-9223
Fax: +86-21-5763-8240
Email: support@adaptivepower.com

Web: <http://www.adaptivepower.com>

2 Front Matter

2.1 Limited Warranty

Adaptive Power Systems, Inc. (APS) warrants each unit to be free from defects in material and workmanship. For the period of one (1) year from the date of shipment to the purchaser, APS will either repair or replace, at its sole discretion, any unit returned to the APS factory in Irvine, California or one of its designated service facilities. It does not cover damage arising from misuse of the unit or attempted field modifications or repairs. This warranty specifically excludes damage to other equipment connected to this unit.

Upon notice from the purchaser within (30) days of shipment of units found to be defective in material or workmanship, APS will pay all shipping charges for the repair or replacement. If notice is received more than thirty (30) days from shipment, all shipping charges shall be paid by the purchaser. Units returned on debit memos will not be accepted and will be returned without repair.

This warranty is exclusive of all other warranties, expressed or implied.

2.2 Service and Spare Parts Limited Warranty

APS warrants repair work to be free from defects in material and workmanship for the period of ninety (90) days from the invoice date. This Service and Spare Parts Limited Warranty applies to replacement parts or to subassemblies only. All shipping and packaging charges are the sole responsibility of the buyer. APS will not accept debit memos for returned power sources or for subassemblies. Debit memos will cause return of power sources or assemblies without repair.

This warranty is exclusive of all other warranties, expressed or implied.

2.3 Safety Information

This chapter contains important information you should read BEFORE attempting to install and power-up APS Equipment. The information in this chapter is provided for use by experienced operators. Experienced operators understand the necessity of becoming familiar with, and then observing, life-critical safety and installation issues. Topics in this chapter include:

- Safety Notices
- Warnings
- Cautions
- Preparation for Installation
- Installation Instructions



Make sure to familiarize yourself with the **SAFETY SYMBOLS** shown on the next page. These symbols are used throughout this manual and relate to important safety information and issues affecting the end user or operator.

SAFETY SYMBOLS



Direct current (DC)



Alternating current (AC)



Both direct and alternating current



Three-phase alternating current




Protective Earth (ground) terminal



On (Supply)



Off (Supply)



Fuse



Caution: Refer to this manual before this Product.



Caution, risk of electric shock

2.4 Safety Notices

SAFETY SUMMARY

The following general safety precautions must be observed during all phases of operation, service, and repair of this instrument. Failure to comply with these precautions or with specific warnings elsewhere in this manual violates safety standards of design, manufacture, and intended use of the instrument. Adaptive Power Systems assumes no liability for the customer's failure to comply with these requirements.

GENERAL

This product is a Safety Class 1 instrument (provided with a protective earth terminal). The protective features of this product may be impaired if it is used in a manner not specified in the operation instructions.

ENVIRONMENTAL CONDITIONS

This instrument is intended for indoor use in an installation category I, pollution degree 2 environments. It is designed to operate at a maximum relative humidity of 80% and at altitudes of up to 2000 meters. Refer to the specifications tables for the ac mains voltage requirements and ambient operating temperature range.

BEFORE APPLYING POWER

Verify that the product is set to match the available line voltage and the correct fuse is installed.

GROUND THE INSTRUMENT

This product is a Safety Class 1 instrument (provided with a protective earth terminal). To minimize shock hazard, the instrument chassis and cabinet must be connected to an electrical ground. The instrument must be connected to the AC power supply mains through a properly rated three-conductor power cable, with the third wire firmly connected to an electrical ground (safety ground) at the power outlet. Any interruption of the protective (grounding) conductor or disconnection of the protective earth terminal will cause a potential shock hazard that could result in personal injury.

FUSES

Only fuses with the required rated current, voltage, and specified type (normal blow, time delay, etc.) should be used. Do not use repaired Fuses or short circuit the fuse holder. To do so could cause a shock or fire hazard.

DO NOT OPERATE IN AN EXPLOSIVE ATMOSPHERE.

Do not operate the instrument in the presence of flammable gases or fumes.

KEEP AWAY FROM LIVE CIRCUITS.

Operating personnel must not remove instrument covers. Component replacement and internal adjustments must be made by qualified service personnel. Do not replace components with power cable connected. Under certain conditions, dangerous voltages may exist even with the power cable removed. To avoid injuries, always disconnect power, discharge circuits and remove external voltage sources before touching components.


DO NOT SERVICE OR ADJUST ALONE.

Do not attempt internal service or adjustment unless another person, capable of rendering first aid and resuscitation, is present.

DO NOT EXCEED INPUT RATINGS.

This instrument may be equipped with a line filter to reduce electromagnetic interference and must be connected to a properly grounded receptacle to minimize electric shock hazard. Operation at line voltages or frequencies in excess of those stated on the data plate may cause leakage currents in excess of 5.0 mA peak.

DO NOT EXCEED LOAD INPUT VOLTAGE RATING.



WARNING

DO NOT EXCEED LOAD INPUT VOLTAGE RATING

This instrument does NOT have a means to disconnect its Load input from a connected power supply. If the voltage applied to the Load input exceeds its maximum rating – even if the load is turned completely off – damage to the load WILL occur. Damage caused by exceeded maximum load input voltage under any circumstance is NOT covered by the manufacturer's product warranty. Remove any load input connections when the load is not in use, even when it is turned off.

DO NOT SUBSTITUTE PARTS OR MODIFY INSTRUMENT.

Because of the danger of introducing additional hazards, do not install substitute parts or perform any unauthorized modification to the instrument. Return the instrument to an Adaptive Power Systems Sales and Service Office for service and repair to ensure that safety features are maintained.

Instruments that appear damaged or defective should be made inoperative and secured against unintended operation until they can be repaired by qualified service personnel.

3 Product Overview

This chapter provides an overview of the APS 41D+42D Series modular programmable DC loads. It introduces the reader to general operating characteristics of these loads.

3.1 General Description

The APS 41D+42D Series modular electronic loads are designed to perform test, evaluation and burn-in of DC power supplies and batteries.

The 41D+42D Series of electronic load modules are operated from within a suitable mainframe. The 44M01, 44M02 and 44M04 mainframes allow 1, 2 or 4 modules to be operated at the same time. The mainframes provide the necessary mains power conversion along with computer and analogue interfaces. Front panel memory store and recall functions are provided. A total of 150 memory locations are available to store the set-up of the load modules within a mainframe. It is also possible to program and recall a test sequence consisting of different steps against time. Please refer to the separate 44M01, 44M02 and 44M04 operating manuals for the mainframe functions.

Mainframe model 44M01: P/N 160901-10

Mainframe model 44M02: P/N 160902-10

Mainframe model 44M04: P/N 160904-10

The APS 41D+42D Series can be operated from the front panel (manual mode) or using RS232, USB, LAN (Ethernet) or GPIB remote control.

The VI curve constant power contours of the various 41D+42D Series modules are shown in the Technical Specification Section. All models have dual range capability for enhanced accuracy and resolution at lower power levels. Maximum current and power capability depends on the specific module type.

3.2 Operating Modes

Available operating modes for all models except 42D5003 are:

- Constant Current (CC) mode
- Constant Resistance (CR) mode
- Constant Voltage (CV) mode
- Constant Power (CP) mode
- LED (LED) mode

Available operating modes for model 42D5003 are:


- Constant Current (CC) mode
- Constant Resistance (CR) mode
- Constant Voltage (CV) mode
- LED (LED) mode

A more detailed explanation of each mode and under what condition each mode is most appropriate to use follows.

3.2.1 Constant Current Mode

This is the most commonly used mode of operating when testing a voltage source such as a DC power supply, battery, AC/DC converter or ADC. In this mode of operation, the load will sink a constant level of current as set by the user, regardless of any voltage variations. A real time feedback loop ensures a stable current under any voltage variation of the DC supply or battery.


This mode is recommended for load regulation testing, loop stability testing, battery discharge testing and any other form of voltage regulation loop testing.



3.2.2 Constant Resistance Mode

In Constant Resistance mode, the load will sink current directly proportional to the sensed DC input voltage. The ratio between DC voltage and current is linear per ohms law and can be set by the user within the operating range of the DC load. The current is defined by the formula shown here where R is the set value in CR mode and V is the dc input voltage from the unit under test.

$$I = V/R$$




CR mode is useful for battery discharge testing of battery systems used to power constant impedance loads as the voltage will decrease as the battery discharges over time resulting in reduced current sinking.

3.2.3 Constant Voltage Mode

In Constant Voltage mode, the load will attempt to sink as much current as needed to reach the programmed voltage setting. This mode should only be used with current controlled DC power sources.

Note: Most DC power supplies are voltage controlled, i.e. they regulate the output voltage to a predefined voltage level. Such DC voltage supplies should not be tested using CV mode as the DC supply voltage regulation loop will conflict with the DC load control loop.




3.2.4 Constant Power Mode

In Constant Power mode, the DC load will attempt to maintain the programmed Power dissipation by sinking more or less current at the voltage sensed. The current is defined by the formula shown below.

$$I = P/V$$

Constant power mode is useful for battery discharge testing as it simulates constant power drain on the battery, regardless of battery charge state.


Note: This mode is not available on the dual channel 42D5003 load module.



3.2.5 LED Mode

In the LED mode of operation, the 41D+42D load module simulates the VI curve of an LED.

As voltage is applied to the 41D+42D series load, current does not flow until the voltage reaches the V_d load on threshold setting. As the input voltage increases, the load sinks current along the R_d sloped curve as shown in the figure to the right until it reaches I_o . The formula for the load current is $V_o = (I_o * R_d) + V_d$. As the voltage approached V_o , the load transitions into a constant current mode of operation.



The user can set values for V_o , V_d and R_d .

3.3 Static versus Dynamic Operating Modes

The 41D series supports both STATIC and DYNAMIC CC mode. Static mode uses a constant load level whereas dynamic mode allows rapid changes between two pre-set current sink levels using programmable current slew rates and duty cycle.

Note: Dynamic Mode is not available on the dual channel load, model 42D5003.

Static Constant Current mode presents a static load condition as the load current remains constant. This tests load regulation of a DC power supply under steady state operating conditions.

To test voltage regulation under dynamic load conditions, specific changes in current level and current slew rates must be applied to the DC supply under test. The dynamic CC mode is provided for this application.

The 41D series offer a wide range of dynamic load conditions with independent rise and fall current slew rate programming in Constant Current mode.




Figure 3-1: Dynamic Current Wave Form

3.3.1 Programmable Parameters

There are six programmable parameters to generate dynamic wave form or pulse wave form, the 41D series loads will sink current from power source proportional to the dynamic wave form, the dynamic wave form definition is shown in Figure 3-1. Available settings are:

Parameter	Description	Type
Current High	Highest programmed load current	Current Setting
Current Low	Lowest programmed load current	Current Setting
T-High	Duration at High current setting	Time (secs)
T-Low	Duration at Low current setting	Time (secs)
Rising Slew Rate	Current Slew Rate from Low to High Current	A/sec
Falling Slew Rate	Current Slew Rate from High to Low Current	A/sec

Table 3-1: Dynamic Current Mode Parameters

The resulting current waveform has the following characteristics:

$$\text{Period} = T\text{-High} + T\text{-Low}$$

$$\text{Frequency} = 1 / (T\text{-High} + T\text{-Low})$$

$$\text{Duty Cycle} = T\text{-High} / (T\text{-High} + T\text{-Low})$$

3.3.2 Slew Rates

Slew rate is defined as the change in current or voltage over time. A programmable slew rate allows a controlled transition from one load setting to another to minimize induced voltage drops on inductive power wiring, or to control induced transients on a test device (such as would occur during power supply transient response testing).

In cases where the transition from one setting to another is large, the actual transition time can be calculated by dividing the voltage or current transition by the slew rate. The actual transition time is defined as the time required for the input to change from 10% to 90% or from 90% to 10% of the programmed current excursion. In cases where the transition from one setting to another is small, the small signal bandwidth of the load limits the minimum transition time for all programmable slew rates. Because of this limitation, the actual transition time is typically longer than the expected time based on the slew rate setting, as shown in Figure 3-2.

Therefore, both minimum transition time and slew rate must be considered when determining the actual transition time. *See also section 5.13 "Load Current Slew Rate" on page 37.*




Figure 3-2: Rise Time Performance Limits

3.3.3 Determining Actual Transition Times

The minimum transition time (Tr_{min}) for a given slew rate applies for smaller changes in current as a percent of current range. At about a 30% or greater load change, the slew rate starts to increase from the minimum transition time to the maximum transition time (Tr_{max}) at a 100% load change. The actual transition time will be either the minimum transition time, or the total slew time (T-fall or T-rise) divided by the current slew rate, whichever is longer.

Minimum Tr

Use the following formulas to calculate the minimum transition time for a given slew rate on a 41D3002 module:

Maximum current range for this module is 2A so 30% of 2 = 0.6. The minimum required slew rate can be calculated as follows:

$$Tr_{min} = \frac{0.6}{slew\ rate\ (A/s)} * \frac{(90\% - 10\%)}{100\%} \mu s$$

Which is equivalent to:

$$Tr_{min} = \frac{0.6}{slew\ rate\ (A/s)} * 0.8\ \mu s$$

For a programmed slew rate of 0.1A/s, this results in:

$$Tr_{min} = \frac{0.6}{0.1} * 0.8\ \mu s = 4.8\ \mu s$$

Example 1:

Assume high current level (CCH) = 0.3A and low current level (CCL) = 0A. For a 41D3002, a 0.3A delta change in current represents less than 30% of full scale current this load module (< 0.6A). If the programmed slew rate is set to 0.1A/s, the expected transition time would be:

$$Tr = \frac{0.8 * (0.3 - 0)}{0.1} \mu s = 2.4 \mu s$$

However, we determined that Tr_{min} for a slew rate of 0.1A/s is at least 4.8 μs so the actual transition time will be limited to no less than 4.8 μs .

Maximum Tr

Use the following formula to calculate the maximum transition time for a given slew rate:

$$Tr_{max} = \frac{2 (Max.Current)}{slew\ rate\ (A/s)} * 0.8 \mu s$$

For a slew rate of 0.1A/s, this results in:

$$Tr_{max} = \frac{2}{0.1} * 0.8 \mu s = 16 \mu s$$

Example 2:

Assume high current level (CCH) = 1.0A and low current level (CCL) = 0A. Since 1.0A represents more than 30% of the current range for the module used (1.0 > 0.6). If the slew rate is set to 0.1A/s, the expected transition time would be:

$$Tr = \frac{0.8 * (1 - 0)}{0.1} \mu s = 8 \mu s$$

Since Tr_{max} for a slew rate of 0.1A/s is 16 μs so the actual transition time will be lesser of these two values or 8 μs .

3.4 Current Read-back

The load current levels and load status can be set from the front panel of each load module or over the remote control interface. During testing, load input voltage and load current can be read back but the current read back will typically display the average current level unless the dynamic current frequency setting is low enough. An analog current monitor output is provided to allow capturing of dynamic current on a digital storage scope or data recorder.

3.5 Product Features

The following key characteristics apply to all 41D+42D Series modules.

- Fully programmable electronic DC load with flexible configuration and dual range capabilities.
- CC, CR, CV, CP, LED, Dynamic and Short Operating Modes. (excl. model 42D5003)
- CC, CR, CV, LED and Short Operating Modes (model 42D5003)
- PWM control signal for LED driver operation
- Full remote control of all load settings and metering read back.
- Dual high accuracy and high-resolution 5 digit voltage and current meters.
- Built-in pulse generator includes wide Thigh/Tlow dynamic load range, independent Rise/Fall load current slew rate control, and High/Low load level. (excl. model 42D5003)
- Controllable load current slew rate of load level change,
- Load ON/OFF switch change and power supply turn ON.
- Short circuit test with current measure capability.
- Dedicated over current and over power protection test functions
- Automatic voltage sensing and external sense.
- Full protection from over power, over temperature, over voltage, and reverse polarity.
- Current monitor output signal (non-isolated)
- Variable fan speed control for quieter operation

3.6 Accessories Included

The following accessories are included with each 41D+42D Series DC Load in the quantities shown in the table below. If one or more of these items is missing upon incoming inspection of the product, please contact Adaptive Power Systems customer service.

Item	Description	41L	42L	41D	42D
a	Banana plug, 4 mm, Red – Load connection	1	2	1	-
b	Banana plug, 4 mm, Black – Load connection	1	2	1	-
c	Banana plug, 2 mm, Red – V _{SENSE} connection	1	2	3	8
d	Banana plug, 2 mm, Black – V _{SENSE} connection	1	2	3	8
e	Y-hook Terminal, Large – Load connection	2	-	-	-
f	Y-hook Terminal, Small – Load or V _{SENSE} connection	2	4	4	4
g	BNC Cable, 3 feet – I Monitor	1	-	1	-
h	Operator Manual in Hardcopy format or PDF on CD ROM	1	1	1	1
i	Certificate of Conformance	1	1	1	1

Table 3-2: Included Accessories




Figure 3-3: 41D+42D Series Accessories

3.6.1 Accessory Installation

Several connectors are included in the 41D and 42D series ship kit to allow connection of load and sense wires to equipment unit under test (EUT). The following illustrations show how these connectors can be used to connect a load. Note that for lower impedance connections as may be desirable in high current applications, use of the banana jacks and Y-hooks (spade lugs) can be combined.




Figure 3-4: Load and sense connections using Y-hooks/spade lugs




Figure 3-5: Load and sense connections using banana plugs - insertion




Figure 3-6: Load and sense connections using banana plugs - inserted

3.7 Interface Options

Refer to mainframe manual for list of available interface options.

4 Technical Specifications

Technical specifications shown here apply at an ambient temperature of $25^{\circ}\text{C} \pm 5^{\circ}$. Refer to V-I curve and Very Low Voltage V-I Curve charts by models for operating envelope.

4.1 Operating Ranges

MODEL	41D3002	41D1020	41D5002	42D5003
Power Ranges	0-150 W	0-300 W	0-300 W	0-120 W
Current Ranges	0 - 0.6 A 0 - 2 A	0 - 0.6 A 0 - 20 A	0 - 0.6 A 0 - 2 A	0-0.6A 0-2.4A
Voltage Range	0 - 300 V	0 - 100 V	0 - 500 V	0 - 500 V
Minimum Voltage	6 V @ 2 A	0.7 V @ 20 A	6 V @ 2 A	6 V @ 2 A

4.2 Operating Modes

MODEL	41D3002	41D1020	41D5002	42D5003
OPERATING MODES				
CC Mode Range	0 - 0.6 A 0 - 2 A	0 - 0.6 A 0 - 20 A	0 - 0.6 A 0 - 2 A	0 - 0.6 A 0 - 2.4 A
Resolution	0.01mA 0.04mA	0.1mA 0.4mA	0.01mA 0.04mA	0.01mA 0.04mA
Accuracy	$\pm 0.1\%$ OF (SETTING + RANGE)			
CR Mode Range	125-125k Ω 3.00-125 Ω 5-5k Ω 0.05-5 Ω	250-250k Ω 3.00-250 Ω 10-10k Ω 2.5-2.5k Ω		
Resolution	0.133 μS 2.0833 m Ω 3.3 μS 0.0833 m Ω	0.0666 μS 4.1666 m Ω 1.6665 μS 6.666 μS		
Accuracy	$\pm 0.2\%$ OF (SETTING + RANGE)			
CV Mode Range	0 - 30.0 V 0 - 300 V 0-12.0 V 0 - 100 V	0-60.0 V 0 - 500 V 0-60.0 V 0 - 500 V		
Resolution	0.5 mV 5 mV 0.2 mV 2 mV	0.1 mV 10 mV 0.12 mV 10 mV		
Accuracy	$\pm 0.05\%$ OF (SETTING + RANGE)			
CP Mode Range	0 - 150 W	0 - 300 W	0 - 300 W	N/A
Resolution	2.5 mW	5 mW	5 mW	N/A
Accuracy	$\pm 0.5\%$ OF (SETTING + RANGE)			
LED Mode Vo Range	0 - 300 V	0 - 100 V	0 - 500 V	0 - 500 V
Rd Res. Range	2.5-120 Ω @ Vo-Vd=0-6V	2.5-120 Ω @ Vo-Vd=0-6V	2.5-120 Ω @ Vo-Vd=0-6V	2.5-120 Ω @ Vo-Vd=0-6V
	12.5-600 Ω @ Vo-Vd=6-30V	12.5-600 Ω @ Vo-Vd=6-30V	12.5-600 Ω @ Vo-Vd=6-30V	12.5-600 Ω @ Vo-Vd=6-30V
	125-6K Ω @ Vo-Vd=30-300V	125-6K Ω @ Vo-Vd=30-300V	125-6K Ω @ Vo-Vd=30-300V	125-6K Ω @ Vo-Vd=30-300V
Resolution	16 bits			
Accuracy	Vd : $\pm (0.05\%$ OF SETTING + 0.1% OF RANGE), Rd : $\pm (0.05\%$ OF SETTING + 0.1% OF RANGE)			

4.3 Protection Modes

MODEL	41D3002	41D1020	41D5002	42D5003
PROTECTION				
Over Power (OP)	157.5 W	315.0 W	315.0 W	126.0 W 126.0 W
Over Current (OC)	2.1 A	21.0 A	2.1 A	0.63 A 2.52 A
Over Voltage (OV)	315.0 V	105.0 V	525.0 V	525.0 V 525.0 V
Over Temperature (OT)	+90° C / +194° F			

4.4 Dynamic Operation Mode

MODEL	41D3002	41D1020	41D5002	42D5003
DYNAMIC OPERATION				
T high & T low	50 μ s TO 9.999 s (20 kHz)			N/A
Resolution	1 μ s / 10 μ s / 0.1 ms / 1.0 ms			N/A
Accuracy	resolution + 50 ppm			N/A
Slew Rate	0.48-30mA/ μ s	1.92-120mA/ μ s	4.8-300mA/ μ s	19.2-1200mA/ μ s
	0.12mA/ μ s	0.48mA/ μ s	1.2mA/ μ s	4.8mA/ μ s
Accuracy	\pm 5% OF SETTING \pm 10 μ s			N/A
Min. Rise Time	20 μ s Typical			N/A

4.5 Metering

MODEL		41D3002		41D1020		41D5002		42D5003			
METERING											
Voltage	Range	0 - 60.0 V	0-300.0 V	0 - 30.0 V	0 - 100.0 V	0 - 60.0 V	0 - 500.0 V	0-75V	0-500V	0-75V	0-500V
	Resolution	1 mV	5 mV	0.5 mV	2 mV	1 mV	10 mV	1.25mV	10 mV	1.25mV	10 mV
	Accuracy	± 0.025% OF (READING + RANGE)									
Current	Range	0 - 0.6 A	0 - 2.0 A	0 - 6.0 A	0 - 20.0 A	0 - 0.6 A	0 - 2.0 A	0-0.6A	0-2.4A	0-0.6A	0-2.4A
	Resolution	10 µA	40 µA	0.1mA	40 µA	10 µA	40 µA	10 µA	40 µA	10 µA	40 µA
	Accuracy	± 0.1% OF (READING + RANGE)									
Power	Range	0 - 15.0 W	0 - 150.0 W	0 - 30.0 W	0 - 300.0 W	0 - 30.0 W	0 - 300.0 W	0 -12W	0-120W	0 -12W	0-120W
	Accuracy	± 0.125% OF (READING + RANGE)									

4.6 PWM Diming Controls

MODEL	41D3002	41D1020	41D5002	42D5003
PWM DIMING CONTROLS				
Level	Range	0 - 10 V		
	Resolution	50 mV		
	Accuracy	± 1% OF (SETTING + RANGE)		
Frequency	Range	DC to 1000 Hz		
	Resolution	10 Hz		
Duty Cycle	Range	0.01 - 0.99 (1% - 99%)		
	Resolution	0.01		

4.7 Shorting Relay (Option)

MODEL	41D3002	41D1020	41D5002	42D5003
EXTERNAL SHORTING RELAY				
Short Signal Output Level	12 V @ 100 mA max			

4.8 AC Input & Cooling

MODEL	41D3002	41D1020	41D5002	42D5003
AC INPUT AND COOLING SPECIFICATIONS				
AC Power	Supplied by 44M0X Mainframe			
Cooling	Supplied by 44M0X Mainframe			

4.9 Dimensions & Weight

MODEL	41D3002	41D1020	41D5002	42D5003
DIMENSIONS AND WEIGHT				
Dimensions (H x W x D)	143 x 108 x 412 mm / 5.6" x 4.25" x 16.2"			
Weight (Net)	3.7 kg / 8.2 lbs	3.7 kg / 8.2 lbs	3.7 kg / 8.2 lbs	3.7 kg / 8.2 lbs

4.10 Environmental



MODEL	41D3002	41D1020	41D5002	42D5003
ENVIRONMENTAL				
Operating Temperature	0 - 40° C / 32 - 104° F			
Temperature Coefficient	100 ppm / °C typical			
Relative Humidity	80% max. non-condensing			
Environmental	Indoor Use Only, Pollution Degree 2			
Altitude	2000 meter / 6500 feet max. Operating			
EMC & Safety	CE Mark			

4.11 Voltage versus Current Operating Envelope Charts



Following charts show constant power operating envelopes for each module. For operation at voltages below 1.0 Vdc, refer to the Low Voltage Operating charts. Operation below the red line shown in these charts is not specified.

Charts are shown by model on following pages.



4.11.1 Model 41D3002 V-I Curves





4.11.2 Model 41D1020 V-I Curves



4.11.3 Model 41D5002 V-I Curves



4.11.4 Model 42D5003 V-I Curves



5 Unpacking and Installation


5.1 Inspection

The 41D+42D Series DC loads are carefully inspected before shipment. If instrument damage has occurred during transport, please inform Adaptive Power Systems' nearest sales and service office or representative.

5.2 Load Module Installation and Removal in Mainframe

The 41D+42D Series load modules must be installed in a suitable 44M0X mainframe chassis to be used. The mainframe provides all required bias supply voltages as well as force air cooling of the load module(s).

If ordered at the same time as a 44M0X mainframe, the load modules on the same purchase order will be shipped already installed from the factory. If a load module requires installation or removal in the field, the end user can perform this task easily using the steps below.



5.2.1 Module Removal

1. First, ensure AC power to the 44M0X mainframe is switched **OFF**. Failure to do so may result in damage to the load module. The load modules are NOT hot-swappable.
2. Loosen and completely remove the Phillips screw in the lower right hand corner of the load modules front panel. This screw prevents the load module from sliding out of its slot position.
3. Once the screw is removed, the handle can be pulled forward to level the module out of its back plane connectors.
4. Once the level has been pulled as far as it will go, the module can be slid out carefully by pulling it forward until it completely clears the mainframe front bezel.

Refer to Figure 5-3 on next page for an illustration.





Figure 5-1: Load Module Removal

5.2.2 Module Installation

To install a new or different module in an available slot, follow the removal procedure in reverse order.

5.3 Cleaning

To clean this product uses a soft or slightly damp cloth.



CAUTION

BEFORE you clean the unit, switch the mains power off and disconnect the input line cord.

- **Please do NOT use any organic solvent capable of changing the nature of the plastic such as benzene or acetone.**
- **Please ensure that no liquid is allowed to penetrate this product.**

5.4 Powering Up

The following procedure should be followed before applying mains power:

1. Check that the POWER switch is in the OFF (O) position.
2. Verify that the rear panel voltage selector of the chassis is correctly set.
3. Check that nothing is connected to any of the DC INPUT (load input terminals) on the front and/or rear panels.
4. Connect the correct AC mains line cord to the 41D+42D Series load AC input terminal.
5. Plug the line cord plug into a suitable AC outlet socket.
6. Turn on (I) the POWER switch.
7. If the instrument does not turn on for some reason, turn OFF the POWER switch and verify the presence of the correct AC line input voltage using appropriate safety measures.

5.5 In Case of Malfunction

In the unlikely event of an instrument malfunction or if the instrument does not turn on despite the presence of the correct AC line voltage, please attach a warning tag to the instrument to identify the owner and indicate that service or repair is required. Contact Adaptive Power Systems or its authorized representative to arrange for service.

5.6 Load Connections



WARNING

DO NOT EXCEED LOAD INPUT VOLTAGE RATING

This instrument does NOT have a means to disconnect its Load input from a connected power supply. If the voltage applied to the Load input exceeds its maximum rating – even if the load is turned completely off – damage to the load WILL occur. Damage caused by exceeded maximum load input voltage under any circumstance is NOT covered by the manufacturer's product warranty. Remove any load input connections when the load is not in use, even when it is turned off.

When setting up for a new test and connecting any equipment to the DC load, proceed as follows:

1. Always make sure the DC load is turned OFF at the POWER switch when making any wire connections.
2. Check that the output of the equipment under test is **OFF**.
Note: Some power equipment's output may still be energized even if the equipment has been turned off or its output is turned off. This is especially true for DC power supplies.

Note: When working with batteries, it is recommended to provide a suitable disconnect relay or switch so the load connection can be disconnected from the battery for handling purposes.
3. Connect one end of the load wires to the load input terminals on the rear panel.
4. Check the polarity of the connections and connect the other end of the load wires to the output terminal of the equipment under test.
5. When connecting multiple loads to the same EUT, make sure the load wire lengths to each load are the same.

5.7 Analog Programming Input

The 41D series load modules have an analog programming input located on the rear panel of the 44M0X mainframe. This feature allows an external waveform to be tracked as long as it is within the load's dynamic capabilities. These inputs will accept a 0-10V signal. This signal is proportional to the load's maximum current range.

Note: This capability is not available on the dual channel, 42D5003 load module.




Figure 5-2: Location and Pin-out of Analog Programming Input Connector

Channel positions are numbered from left to right when facing the front of the mainframe as shown in the illustration below.




Figure 5-3: Channel Positions for Analog Input Identification

The analog programming input operates in CC or CP modes only. The load module will attempt to load proportionally according to the signal and the load module's maximum current or power range.

For example: 4: $I_{max} = 2A$ and $P_{max} = 150W$

- In CC mode, if the analog programming input is 4V, the load current will be $0.4 \times 2 = 0.8A$.
- In CP mode, if the analog programming input is 1V, the load power setting will be $0.1 \times 150 = 150W$.

The analog programming signal can act alone or it can be summed with the programmed value set via the front panel or the optional computer interface (GPIB, RS232, USB, or LAN) or the front panel.

Figure 5-6 shows the result of an analog programming signal at 4Vac, 500Hz when it is summed with a 0.8A programmed setting in CC mode of DC load.




Figure 5-4: Analog Programming Example

5.8 Load Current Slew Rate

The programmable current slew rate of the DC load allows control over the rate of change in current any time a change in current occurs. This controls the load current slew rate during load current level changes, power supply turn ON/OFF events or when turning the LOAD ON, and OFF. The 41D series loads provide controlled current slewing under all of these conditions. The rise and fall current slew rate can each be set independently.

Rise and fall slew rates can be independently programmed. This allows an independent controlled transition from Low load current level to High load current level (Rise current slew rate) or from High load current level to Low load current level(Fall current slew rate) to minimize induced voltage drops on the wiring inductance, or to control induced voltage transients on the device under test (power supply transient response testing).

See under "DYNAMIC OPERATION, Slew Rate" in the specification section on page 24 for slew rate programming range by model.

This controllable load current slew rate feature also can eliminate the overload current phenomenon and emulate the actual load current slew rate at turn ON of the power supply under test. Figure 5-7 shows the load current slew rate is according to the power supply's output voltage, load level setting and Load ON/OFF switch.

The ability to apply all these dynamic current characteristics at the same time using the Constant Current mode of the 41D series load greatly speeds up power supply testing tasks. This can significantly improve the test quality, thoroughness and efficiency.

There are two load current ranges in 41D series Load, Range I and Range II, the rise and fall




Figure 5-5: Effect of Current Slew Rate Settings on Power Supply Testing

slews rate range for both current ranges is specified in Section 4.1, “Technical Specifications” on page 24.

6 Front Panel Operation

This Chapter provides an overview of front panel operation for the 41D+42D Series DC Loads. For remote control operation, refer to Section 8 “Remote Control Programming” of this manual for an overview of available programming commands.

6.1 Front Panel Layout

The front panel layout is shown in Figure 6-1 below. Rack handles and ears are shown but can be removed if the unit will only be used on the bench.




Figure 6-1: 44M04 Chassis with 41L0630 Series Loads Front Panel View

Each load module has its own dedicated LCD readouts located along the top. User controls are located below these displays. Along the bottom edge of the 44M04 chassis, memory bank controls are positioned next to a separate memory bank and system setting display. The power ON/OFF switch is found in the lower left corner.

6.2 41D Series User Controls and Readouts

The following user controls, indicator and displays are common to all 41D+42D Series load models. The purpose and function of each control and indicator is explained in the table below. Refer to figure for the location of each control and indicator.




Figure 6-2: Front Panel User Controls and Indicators

The various controls and indicators are explained in more detail in the table below. The Item numbers correspond to the indices in Figure above.

KEY#	Description
1	Indicates the model number and key performance specifications of the load.
2	Go/NoGo indicator illuminates if upper or lower limit settings are exceeded.
3	<p>There are five operating modes can be selected by pressing the "MODE" key on the electronic load. The sequence is Constant Current (CC), Constant Resistance (CR), Constant Voltage (CV), Constant Power (CP), LED Mode (LED) and then repeats. When pressing the "MODE" key, the CC, CR, CV, CP mode indicator will be lit respectively when the appropriate operating mode is selected. The operating theorem of CC, CR, CV, CP and LED mode is described in Section 3.2, "Operating Modes".</p> <p>There are two programming ranges in CC, CR, CV and CP mode respectively; the 41D+42D Series load can adjust to the optimal range automatically according to the programmed load level. The range selection criteria are described below for each operating mode.</p>

KEY#	Description	
	CC Mode	<p>The Range I (0.6A) indicates low load current operating range; Range II (2A) indicates high load current operating range. The specification of load current ranges is listed in Section 4.1. The current range is changed automatically in accordance to the programmed load current.</p> <p>Range I is selected automatically if the programmed load current is less than the maximum current of Range I, and will be set to Range II automatically when the programmed current is higher than the maximum current of Range I.</p>
	CR Mode	<p>Range I indicates low load resistance operating range, Range II indicates high load resistance operating range. The specification of the resistance ranges is shown in section 4.1, "Operating Ranges". The resistance range is changed automatically in accordance to the programmed load resistance.</p> <p>The electronic load will switch to Range I automatically if the programmed load resistance is higher than the minimum load resistance of Range I, and will be set to Range II when the programmed load resistance is lower than the minimum load resistance of Range I.</p>
	CV Mode	<p>Range I indicates low load voltage operating range, Range II indicates high load voltage operating range. The specification of voltage ranges is shown in section 4.1, "Operating Ranges". The voltage range is changed automatically in accordance to the programmed load voltage.</p> <p>Range I is selected automatically if the programmed load voltage is less than the maximum voltage of Range I, and will be set to range II automatically when the programmed voltage is higher than the maximum voltage of Range I.</p>
	CP Mode	<p>Range I indicates low load power operating range, Range II indicates high load power operating range. The power range specification is shown in section 4.1, "Operating Ranges". The power range is changed automatically in accordance with the programmed load power.</p> <p>Range I is selected automatically if the programmed load power is less than the maximum power of Range I, and will be set to Range II automatically when the programmed power is higher than the maximum power of Range I.</p>
	LED Mode	In this mode, the load behaviour is determined by the LED setting parameters.
4	The Remote LCD Indicator is used to indicate the status of remote operation. Front panel operation is locked out while the remote LCD annunciator is ON. In case of Local mode or manual operation, the Remote LCD annunciator is OFF	






KEY#	Description
5	<p>The 5 digit LCD display is a multi-function display, the functions are described below:</p> <p>Normal mode:</p> <p>This is a 5 digit DVM display, measuring data of the DC input terminal or V-sense input terminal if V-sense AUTO is programmed. If V-sense ON is programmed, the display shows the voltage at the V-sense input terminal only.</p> <p>When the auto-sense of V-sense function is programmed, the auto-sense circuit of the electronic load can check if the V-sense cable is connected, If the V-sense input detected is greater than 0.7V (e.g. 5L12-24,) or not. If both conditions are true, the 5 digit DVM measures at the sense input (remote V sense); otherwise, the 5 digit DVM measures at the DC input terminals of the load (local V sense).</p> <p>Test Setting Mode:</p> <p>Short: Short test Enable and Short Setting programming: Display will show: "Short".</p> <p>OPP: OPP test Enable and OPP Setting programming: Display will show: "OPP".</p> <p>OCP: OCP test Enable and OCP Setting programming: Display will show: "OCP".</p> <p>During Short, OCP and OPP test programming, this display will show sensed voltage or load Input voltage.</p>
6	<p>This readout can be in one of two modes: Normal or Setting mode.</p> <p>In "Normal" mode, this 5 digit LCD displays the measured current of the DC load when the load is ON.</p>
	<p>In "Setting" mode, this LCD displays the following setting parameters. The rotary knob is used to scroll through these settings:</p> <ol style="list-style-type: none"> 1. Config ON programming: Display will individually show "SENSE", "LDon", "LDoFF", "POLAR", "AVG", "bW" and "RD.DSP". 2. Limit ON programming: Display will individually show "V_Hi", "V_Lo", "A_Hi", "A_Lo", "W_Hi", "W_Lo" and "NG". 3. DYN setting ON programming: Display will individually show "T-Hi", "T-Lo", "RISE" and "FALL". 4. Short setting programming: Display will individually show "TIME", "V-Hi" and "V-Lo". 5. OPP setting programming: Display will individually show "PSTAR", "PSTEP", "PSTOP" and "VTH". 6. OCP setting programming: Display will individually show "ISTAR", "ISTEP", "ISTOP" and "VTH". <p>During Short testing: Display shows the actual load current, the unit is "A".</p> <p>During OCP testing: Display shows the actual load current, the unit is "A".</p> <p>During OPP testing: Display shows the actual power, the unit is "W"</p> <p>When over current protect is tripped: Display shows [OCP].</p>
7	<p>This readout can be in one of two modes: Normal or Setting mode.</p> <p>In "Normal" mode, this 5 digit LCD displays the power dissipated by the DC load when the load is ON.</p>




KEY#	Description
	<p>In "Setting" mode, this LCD displays the following setting parameters. The rotary knob is used to scroll through these settings:</p> <ol style="list-style-type: none"> PRESET ON mode display will individually show: <ol style="list-style-type: none"> CC mode's current programming value display, the unit is "A" CR mode's resistor programming value display, the unit is "Ω" CV mode's voltage programming value display, the unit is "V" CP mode's power programming value display, the unit is "W" If LED mode No is selected, the lower display provides the number set. If LED mode Vo is selected, the lower display provides Vo set value in volts "V". If LED mode Vd is selected, the lower display provides Vd set value in volts "V". If LED mode Rd is selected, the lower display provides Rd set value in ohms "Ω". If LED mode Io is selected, the lower display provides Io set value in amps "A" LIMIT ON mode display will individually show : <ol style="list-style-type: none"> V_Hi (upper limit voltage) & V_Lo (lower limit voltage) value display, the unit is "V" A_Hi (upper limit current) & A_Lo (lower limit current) value display, the unit is "A" W_Hi (upper limit power) & W_Lo (lower limit power) value display, the unit is "W" NG programming display will show [ON] or [OFF] DYN setting ON mode display will individually show : <ol style="list-style-type: none"> T-Hi (level high time) & T-Low (level low time) programming value display, the unit is "ms" Rise/Fall current slew rate programming value display, the unit is "A/us" or "A/ms" Config ON mode display will individually show: <ol style="list-style-type: none"> SENSE programming display shows [ON] or [AUTO] LDon & LDoff value displayed, the unit are "V" Load polarity value display shows [+LOAD] or [-LOAD] bW (Bandwidth) selected [Hi] or [Lo] AVG (Average) number of measurement averaged from 1 to 64 Rd_Io setting as [Rd] or [Io] LED No. settings as [ON] or [OFF] Short test Enable, OCP test Enable and OPP test Enable mode will show [START] Short Setting mode <ol style="list-style-type: none"> Short setting display will show "CONTI", Short time setting; the unit is "ms" V-Hi & V-Low value display, the unit is "V" OPP Setting mode <ol style="list-style-type: none"> OPP PSTAR, OPP PSTEP and OPP PSTOP value display, the unit is "W" OPP Vth value display, the unit is "V". OCP Setting mode <ol style="list-style-type: none"> OCP ISTAR, OCP ISTEP and OCP ISTOP value display, the unit is "A" OCP VTH value display, the unit is "V" <p>During OCP test & OPP test, display will show [RUN]</p> <p>When over power protect: Display will show [OPP]</p> <p>When over temperature protect: Display will show [OTP]</p>
8	<p>MODE and CC, CR, CV, CP, LED Indicator</p> <p>There are five operating modes that can be selected by pressing the "MODE" key. The sequence is Constant Current (CC), Constant Resistance (CR), Constant Voltage (CV), Constant Power (CP), LED mode (LED) and then repeats while pressing the "MODE" key. The CC, CR, CV, CP or LED mode indicator will be lit respectively when the appropriate operating mode is selected.</p>

KEY#	Description
9	<p>LOAD ON/OFF key and LED</p> <p>The load input can be toggled ON/OFF using the front panel's LOAD ON/OFF key. The load current slew rate follows the slew rate setting, so the load current slew rate will change at the programmed Rise/Fall slew rate setting respectively.</p> <p>Turning the LOAD OFF does not affect the programmed settings. The LED is OFF to indicate LOAD OFF status. The LOAD will return to the previously programmed values when the LOAD key is turned to ON again.</p> <p>The Load ON LED indicates the load is ready to sink current from DC input.</p> <ol style="list-style-type: none"> 1. Load ON/OFF key: Switches from load ON to load OFF. The fall slew rate is in accordance with the slew rate setting on the front panel. 2. DC input voltage: There is a load ON and load OFF voltage control circuit in the electronic load. When the Device under Test turns ON, the output voltage of D.U.T will increase up from 0 to rated output voltage. The electronic load will start to sink current after load voltage is higher than load ON voltage configuration setting (See "Config" key). The programmed load ON voltage for the 41D+42D Series load depends on the model. When the device under test (DUT) turns OFF, the output voltage of DUT will decrease down to 0 volt. The electronic load will stop to sink current after load voltage is lower than load OFF voltage configuration setting (See "Config" key). The programmed load OFF voltage for the load is from 0 Vdc to the load ON voltage value.
10	<p>DYN / STA key and LED</p> <p>This key is available in Constant Current and Constant Power mode only. In Constant Resistance and Constant Voltage mode, this key has no function and the LED is OFF. The load will default to static mode. In Constant Current and Constant Power mode, the Static or Dynamic mode is toggled by this key; the LED will be lit if the load is in Dynamic mode.</p>
11	<p>RANGE key and LED</p> <p>RANGE AUTO / II Key is for range selection. If the Range AUTO LED is OFF, the load will be in Range I or II in accordance with the actual current value. When Range the II, LED is ON, the current programming will be locked on Range II.</p>






KEY#	Description
12	<p>LEVEL key and LED</p> <p>The LEVEL key is used to toggle between the High and Low load setting value. This applies in static mode only. In the Dynamic Constant Current mode, the High and Low level are used to define levels of the dynamic waveform.</p> <ol style="list-style-type: none"> 1. In Constant Current mode: The level is initially set to High. LEVEL High / Low has two levels, Low current level setting must be lower than Level High. 2. In Constant Resistance mode: The level is initially set to High. LEVEL High / Low has two levels, Low resistance level setting must be higher than Level High. Note: CR Mode Level High / Low level by current perspectives. 3. In Constant Voltage mode: The level is initially set to High. LEVEL High / Low has two levels, Low voltage level setting must be lower than Level High. Note: CV Mode Level High / Low has "automatic push function." 4. In Constant Power mode: The level is initially set to High. LEVEL High / Low has two levels, Low power level setting must be lower than Level High. <p>Note: Automatic level function: The High level setting must be higher or equal than Low level setting. When High level is equal to Low level, no further adjustment is possible. When the High level equals the Low level, the Automatic level function will adjust the Low level value so the High level value can continue to be adjusted.</p>
13	<p>PRESET ON/OFF key and LED</p> <p>In PRESET OFF state, the load input voltage is shown on the upper 5-digit meter, and load input current is shown on the middle 5-digit meter. The load input power is shown on the lower 5-digit meter. The engineering unit "V", "A" and "W" LCDs will be lit respectively.</p> <p>In Preset ON state, the PRES. LED is ON, the lower 5-digit meter display will be determined by the CC, Dynamic, CR, CV, and CP operating mode.</p> <p>In Preset ON condition, the 5 digit DAM indicates the set load current, which can be from front panel or remote control interface setting.</p> <ol style="list-style-type: none"> 1. In Constant Current mode: The High / Low level load current value can be preset on the lower 5 digit LCD display. The unit is "A" and the "A" will be lit as well. 2. In Dynamic load mode: The Thigh / Tlow parameters value of High / Low load current duration and Rise / Fall setting can be displayed on the lower 5 digit LCD display. The unit is "ms" and the "ms" will be lit as well. 3. In Constant Resistance mode: The High / Low level load resistance value can be preset on the lower 5 digit LCD display. The engineering unit is "Ω" and the "Ω" will be lit as well. 4. In Constant Voltage mode: The High / Low level load voltage value can be preset on the upper 5 digit LCD display. The unit is "V" and the "V" will be lit as well. 5. In Constant Power mode: The High / Low level load power value can be preset on the lower 5 digit LCD display. The unit is "W" and the "W" will be lit as well. 6. In LED mode, the LED parameter set values are displayed on the lower 5 digit display. Press the PRESET key to cycle through each parameter in the following order: No. \Rightarrow Vo \Rightarrow Vd \Rightarrow Rd \Rightarrow Rr \Rightarrow Repeat. Note that these settings can only be changed when PRESET mode is ON.


KEY#	Description
	<p>LED MODE Parameter Setting Screens</p> <p>The LED mode requires LED parameters to be set to mimic the specifications of the LED to be simulated as a load to the equipment under test. Available LED screens are access in the following order:</p> <p>No. ⇒ Vo ⇒ Vd ⇒ I ⇒ Rr ⇒ Rd ⇒ Exit</p>
	<p>LED MODE No.: Set to initial value of 1. This setting simulates the number of cascaded LEDs. Setting range is from 1 to 90 for models 41D3002, 41D5002 and 42D5003 and from 1 to 3 for model 41D1002.</p> <p>NOTE: Changing the quantity of LEDs may result in a possible shift in the value of Rd. Rd automatically switches back to its original setting if you have exceeded the value of the nearest range. After changing the quantity No. value, confirm Vd to see if all settings are correct.</p>



KEY#	Description
	<p>LED MODE Vo: Vo represents the CV mode set voltage across a single LED. Set to initial value of 3.5V or 17.5V depending on load model. The No. setting is used to determine the actual voltage setting reflecting the series string of LEDs. Vo should not exceed the maximum voltage rating of the LED simulated.</p>  <p>When setting the Vo value, the lower LCD display shows the current setting. The unit is "V". Setting range is 0.000V to the full scale of the LED load module specification. Change the setting by rotating the shuttle.</p> 
	<p>LED MODE Vd: Vd is initially set to 80% of the initial value of Vo or $0.8 * 3.5 = 2.8V$ on some models and $0.8 * 17.5V = 14V$ on other models. When changing Vo, Vd will also be adjusted to 80% of Vo set value. Vd is the turn on voltage of a single LED of the.</p>  <p>When setting the Vd value, the lower LCD display shows the current setting. The unit is "V". Setting range is 0.000V to the full scale of the LED load module specification. Change the setting by rotating the shuttle.</p> 
	<p>LED MODE Io: This screen sets the Io parameter value. Use the shuttle or cursor keys to adjust the Io value to the desired LED current specification. When Vo is set to 3.5V and Vd is set to 2.8V, the adjustment range for Io is between 0.00583A and 0.28000A.</p> 




KEY#	Description
	<p>LED MODE Rr: The Rr parameter sets the value of the LED's parallel resistance. Its use is optional and this parameter can be turn OFF. When on, the value of Rr can be set using the shuttle or cursor keys. The settable range depends on the 41D or 42D model:</p> <p>Model 41D3002: 2.4kΩ to 120kΩ Model 41D1020: 480Ω to 24kΩ Model 42D5002: 10kΩ to 500kΩ Model 42D5003: 10kΩ to 500kΩ</p> 
	<p>LED MODE Rd: The Rd parameter sets the value of the LED's series resistance. The initial value is set to 120.0Ω based on the number of series LEDs set and value of (Vo – Vd) which determines the selected adjustment range. Refer to Section 4.2, "Operating Modes" for available ranges by model.</p>  <p>Example below assumes (Vo-Vd) < 0.6V, thus the available adjustment range is from 2.5Ω to 120.0 Ω. Set this value to the LED specification using the shuttle or cursor keys.</p> 
14	<p>LIMIT key and LED</p> <p>The LIMIT key setting includes the GO/NG check of digital voltage meter Upper/Lower limit, current meter Upper/Lower limit, and watt meter Upper/Lower limit within the Limit key setting. The setting sequence is shown below:</p> <p>OFF \Rightarrow DVM Upper/Lower limit \Rightarrow DAM Upper/Lower limit \Rightarrow DWM Upper/Lower limit \Rightarrow GO/NG check ON/OFF \Rightarrow OFF \Rightarrow Repeat</p> <p>The screen images below show the sequence of screens and parameters available to set on each screen. For additional information on using the NG mode, refer to section 6.4, "Go/NoGo LIMIT Testing".</p>

KEY#	Description
	<p>Setting Upper limit voltage V_{Hi}: Middle 5 digit LCD displays [V_{Hi}], lower 5 digit LCD displays the unit in "V". The V_{Hi} set range is from 0.000V to 300.000V. Adjust in 0.01V steps by rotating the dial.</p>





KEY#	Description
	<p>Setting lower limit voltage V_{Lo}: Middle 5 digit LCD displays [V_{Lo}], lower 5 digit LCD displays the unit in "V". The V_{Lo} set range is from 0.000V to 300.000V. Adjust in 0.01V steps by rotating the dial.</p> 
	<p>Setting Upper limit current I_{Hi}: Middle 5 digit LCD displays [I_{Hi}], lower 5 digit LCD displays the unit in "A". The I_{Hi} set range is from 0.000A to 2.0000A. Adjust in 0.0001A steps by rotating the dial.</p> 
	<p>Setting lower limit current I_{Lo}: Middle 5 digit LCD displays [I_{Lo}], lower 5 digit LCD displays the unit in "A". The I_{Lo} set range is from 0.000A to 2.0000A. Adjust in 0.0001A steps by rotating the dial.</p> 
	<p>Setting Upper limit power W_{Hi}: Middle 5 digit LCD displays [W_{Hi}], lower 5 digit LCD displays the unit in "W". The W_{Hi} set range is from 0.00W to 150.00W or 300.00W. Adjust in 0.01W steps by rotating the dial.</p> 
	<p>Setting lower limit power W_{Lo}: Middle 5 digit LCD displays [W_{Lo}], lower 5 digit LCD displays the unit in "W". The W_{Lo} set range is from 0.00W to 150.00W or 300.00W. Adjust in 0.01W steps by rotating the dial.</p> 





KEY#	Description
	<p>Setting NG ON/OFF: When NG is turned on (turn dial for ON or OFF), a NG indication will be displayed when any of the set measurement limits is exceeded.</p> 
15	<p>DYN setting key and LED</p> <p>DYN setting key is to set the Dynamic Mode parameters. They are rise, fall, Thigh and Tlow. Parameters can be changed using the rotary knob. Press any key to escape the DYN parameter setting mode.</p> <ol style="list-style-type: none"> 1. Press DYN setting key, LED will turn ON 2. Setting level High Period: Middle 5 digit LCD display will show "T-Hi", left 5 digit LCD display will show setting value. The unit is "ms" 3. Setting level Low period: Middle 5 digit LCD display will show "T-Lo", left 5 digit LCD display will show setting value. The unit is "ms" 4. Setting rise time: Middle 5 digit LCD display will show "RISE", left 5 digit LCD display will show setting value. The unit is "(m)A/us" 5. Setting fall time: Middle 5 digit LCD display will show "FALL", left 5 digit LCD display will show setting value. The unit is "(m)A/us" <p>The screen images below show the sequence of screens and parameters available to set on each screen. For additional information on using the DYNAMIC mode, refer to section 3.3, "Static versus Dynamic Operating Modes".</p>



KEY#	Description
	<p>The time during which the waveform is high includes the rise time and is set in “ms”. The time during which the waveform is low includes the fall time and is set in “ms”. The RISE and FALL times are set in “mA/μs” or “A/μs”. The actual engineering unit is shown in the bottom right corner of the LCD display.</p> 
	<p>To program the Dynamic mode, proceed as follows:</p> <p>Press DYN setting key. The DYN LED will turn ON. To set the T_Hi high level period, the middle 5 digit LCD display will show [T_Hi]. The lower 5 digit LCD display will show the set value in “ms”. The T_Hi set range is from 0.050 ms to 9999 ms. Adjust in 0.001ms steps by rotating the dial.</p> 




KEY#	Description
	<p>To set the T_{Lo} high level period, the middle 5 digit LCD display will show [T-L0]. The lower 5 digit LCD display will show the set value in “ms”. The T_{Lo} set range is from 0.050 ms to 9999 ms. Adjust in 0.001ms steps by rotating the dial.</p> 
	<p>To set the RISE time, the middle 5 digit LCD display will show [RISE]. The lower 5 digit LCD display will show the current slew rate in “mA/μs”. The slew rate range is from 0.48 mA/μs to 30.00 mA/μs. Adjust in 0.12 mA/μs steps by rotating the dial.</p> 
	<p>To set the FALL time, the middle 5 digit LCD display will show [FALL]. The lower 5 digit LCD display will show the current slew rate in “mA/μs”. The slew rate range is from 0.48 mA/μs to 30.00 mA/μs. Adjust in 0.12 mA/μs steps by rotating the dial.</p> 



KEY#	Description
16	<p>CONFIG key and LED</p> <p>The CONFIG key setting includes the Sense AUTO/ON, Load ON/OFF voltage, Load Polarity, measurement averaging, bandwidth limit, Rd mode and no. of LEDs. Each press of the CONFIG key moves the menu one step. On the first press of the CONFIG key, the CONFIG button will illuminate and SENSE will be displayed on the middle LCD. The value is adjusted with the dial and can be read from the lower LCD during setting. The setting sequence is shown below.</p> <p>SENSE AUTO/ON ⇒ Load ON/OFF Voltage ⇒ Polarity setting ⇒ AVG ⇒ bW (Bandwidth) ⇒ Rd.Display (set Rd or Io) ⇒ LED NO. (ON/OFF) ⇒ Exit</p> <pre> graph TD S1["APS 41D3002 LED DC ELECTRONIC LOAD 300V/2A-150W CC 5.000 V SENSE OFF"] --> S2["APS 41D3002 LED DC ELECTRONIC LOAD 300V/2A-150W CC 5.000 V Load 1.00 V"] S2 --> S3["APS 41D3002 LED DC ELECTRONIC LOAD 300V/2A-150W CC 5.000 V Load 0.50 V"] S3 --> S4["APS 41D3002 LED DC ELECTRONIC LOAD 300V/2A-150W CC 5.000 V POLAR +LOAD"] S4 --> S5["APS 41D3002 LED DC ELECTRONIC LOAD 300V/2A-150W CC 5.000 V AVG 1"] S5 --> S6["APS 41D3002 LED DC ELECTRONIC LOAD 300V/2A-150W CC 5.000 V bW Hi"] S6 --> S7["APS 41D3002 LED DC ELECTRONIC LOAD 300V/2A-150W CC 5.000 V Rd-Io Io"] S7 --> S8["APS 41D3002 LED DC ELECTRONIC LOAD 300V/2A-150W CC 5.000 V LED NO. ON"] S8 --> S9["APS 41D3002 LED DC ELECTRONIC LOAD 300V/2A-150W CC 5.000 V .00000 A 0.000 W"] </pre>




KEY#	Description
	<p>Setting the Vsense mode: Press the CONFIG key. The middle 5 digit LCD display will show "SENSE". The lower 5 digit LCD display will show "AUTO" or "ON". Use the rotary dial to toggle the setting.</p> 
	<p>Setting the LOAD ON voltage levels: Press the CONFIG key twice. The middle 5 digit LCD display will show "LDON". The lower 5 digit LCD display will show the set value in Volts. The Load ON Voltage set range for 41D and 42D modules is from 0.0V to 300V in 0.01V steps. Adjust by rotating the dial. If the input voltage to the load is greater than the Load ON voltage setting, the load starts to sink current.</p>  <p>Notes:</p> <ol style="list-style-type: none"> 1. The adjustable LOAD ON voltage (LD ON) is valid for CC, CR & CP operating modes only. It does not operate in CV mode. 2. The LOAD ON voltage setting cannot be lower than the LOAD OFF voltage setting. If 0V is required for both LOAD ON and LOAD OFF, make the LOAD OFF adjustment first.
	<p>Setting the LOAD OFF voltage levels: Press the CONFIG key till the LOAD OFF screen appears. The middle 5 digit LCD display will show "LDOFF". The lower 5 digit LCD display will show the set value in Volts. The Load OFF Voltage set range for 41D and 42D modules is from 0.0V to 499.50V in 0.01V steps. Adjust by rotating the dial. If the input voltage to the load is less than the Load OFF voltage setting, the load turns off.</p> 
	<p>Setting the Load polarity: Press the CONFIG key till the POLARITY screen appears. The middle 5 digit LCD display will show "POLAR". The lower 5 digit LCD display will show "+ LOAD" or "-LOAD". Use the dial to toggle between "+ LOAD" or "-LOAD" settings.</p> 



KEY#	Description
	<p>Setting AVERAGING: Press the CONFIG key till the AVERAGE screen appears. The middle 5 digit LCD display will show "AVG". The lower 5 digit LCD display will show the AVERAGING count. The averaging range is from 1 (default) to 64 in 1 increments. Adjust by rotating the dial. Averaging of measurements results in more stable readings but slows down the measurement update rate. If averaging is required, chose a setting that best balances stability of readings with update rate.</p> 
	<p>Setting bW (Bandwidth): Press the CONFIG key till the bandwidth screen appears. The middle 5 digit LCD display will show "bW". The lower 5 digit LCD display will show [HI] or [LO]. Toggle setting by rotating the dial. Using low bandwidth results in more stable operation with some LED power supplies.</p> 
	<p>Setting Rd.Display: Press the CONFIG key till the RD.DSP screen appears. The middle 5 digit LCD display will show "Rd_Io". The lower 5 digit LCD display will show the setting as either Io (default) or Rd. Toggle setting by rotating the dial.</p> 
	<p>Setting LED NO.: Press the CONFIG key till the LED NO. screen appears. The middle 5 digit LCD display will show "LED". The lower 5 digit LCD display will show "NO. ON" or "NO. OFF". Toggle setting by rotating the dial.</p> 




KEY#	Description
17	<p>SHORT key and LED Functions</p> <p>Short test function Enable/Disable Key: Press the “SHORT” key to enable the short test function. The indicator LED will be lit. The LCD display shows “SHORT” on the upper 5-digit LCD display, shows “PRESS” on the middle 5-digit LCD display and shows START” on the lower 5-digit LCD display.</p>  <p>Short test function parameter setting key: There are three parameters for the SHORT test function. The parameters are: TIME, V-Hi and V-Lo. Press the “SHORT” key again to set short test time when the SHORT test function is enabled. Press SHORT key again to proceed to the next parameter and follow the sequence of TIME, V-Hi, V-Lo and Disable. Press any another key to exit and save the SHORT settings.</p>  <p>The SHORT test parameter descriptions are as follows:</p>

















KEY#	Description
	<p>a. TIME: Setting the short test time. The LCD display shows "SHORT", "TIME" and CONT (or initial setup value) on the top to bottom 5-digit LCD displays. The setting range is "CONTI" which means continuous or 100ms to 10000ms in 100ms steps. Turn the rotary knob clockwise to adjust this the setting. The short test will have no time limitation when set to "CONTI" until the "START/STOP" key is pressed to stop the short test.</p> 
	<p>b. V-Hi: Short test voltage check upper limitation setting. The LCD displays show "SHORT", "V-Hi" and 0.00V (or initial setup value) from top to bottom. The V-Hi setting range is from 0.00 to 300.00V in 0.01V steps and can be adjusted by turning the rotary knob.</p> 
	<p>c. V-Lo: Short test voltage check lower limitation setting. The LCD displays show "SHORT", "V-Lo" and 0.00V (or initial setup value) from top to bottom. The V-Lo setting range is from 0.00 to 300.00V in 0.01V steps and can be adjusted by turning the rotary knob.</p> 
	<p>Note: The V-Hi and V-Lo parameters of the SHORT test are different from the V-Hi and V-Lo settings of the LIMIT function.</p>
	<p>START/STOP Test key. Press the "START/STOP" key to start or stop the SHORT test when SHORT test function is enabled.</p> <p>The Load will go to "ON" state automatically when the "START/STOP" key is pressed and start the SHORT test. The Load will go to "OFF" state automatically when the "START/STOP" key is pressed to stop the short test. However, the Load will stay in the "ON" state if the load was "ON" before SHORT test execution.</p> <p>The SHORT test function is used to the UUT's short circuit protection function. The SHORT test will sink the load's full scale current until the UUT's voltage drop is between the set V_Hi and V_Lo limits. The lower 5-digit LCD display will shows "PASS", otherwise it will show "FAIL".</p> <p>Press any key to return to normal mode LCD display.</p>



KEY#	Description
18	<p>OCP key and LED Functions</p> <p>OCP test function Enable/Disable Key. Press the “OCP” key to enable the OCP test function and the indicator LED will be lit. The LCD display shows “OCP” on right 5-digit LCD display, shows “PRESS” on the middle 5-digit LCD display and shows “START” on left 5-digit LCD display.</p> 
	<p>OCP test function parameter settings. There are four parameters for the OCP test function. These parameters are: ISTAR, ISTEP, ISTOP and Vth. Press the “OCP” key again to set the OCP test parameter ISTAR(start current point) Press the “OCP” key again to proceed to the next parameter in order of ISTEP, ISTOP, Vth and Disable. Press any another key to exit the and save the OCP settings. The OCP test parameter descriptions are as follows:</p>
	<p>a. ISTAR: Setting the start current point. The LCD display shows “OCP”, “ISTAR” and 0.000A (or initial setup value) from top to bottom on the 5-digit LCD displays. The setting range is 0.000A to the full scale of the CC mode specification. This parameter can be adjusted by turning the rotary knob.</p> 

KEY#	Description
	<p>b. ISTEP: Setting the increment current step size. The LCD display shows "OCP", "ISTEP" and 0.0001A (or initial setup value) from top to bottom on the 5-digit LCD displays. The setting range is 0.0001A to the full scale of the CC mode specification. This parameter can be adjusted by turning the rotary knob.</p> 
	<p>c. ISTOP: Setting the stop current point. The LCD display shows "OCP", "ISTOP" and 0.0000A (actual value depends on 41D+42D series model) from top to bottom on the 5-digit LCD displays. The setting range is 0.000A to the full scale of the CC mode specification. This parameter can be adjusted by turning the rotary knob.</p> 
	<p>d. Vth: Setting the threshold voltage. The LCD display shows "OCP", "Vth" and 0.00V (or initial setup value) from top to bottom on the 5-digit LCD displays. The setting range is 0.00V to the full scale of the Voltage specification. This parameter can be adjusted by turning the rotary knob.</p> 
	<p>START/STOP Test key. Press START/STOP key to start or stop the OCP when the OCP test function is enabled.</p> <p>The Load will go to the "ON" state automatically when the "START/STOP" key is pressed and start the OCP test. The load will return to the "OFF" state automatically when the "START/STOP" key is pressed to stop the OCP test. The load will remain in the "ON" state if the load was "ON" before OCP test execution.</p> <p>The OCP test function tests the UUT's over current protection function. The OCP test will start sinking current from I-START and increase by ISTEP current until the UUT's output voltage drops below the threshold voltage(V-th setting), and the OCP trip point is between the A_Hi and A_Lo limit settings. The lower 5- digits LCD display will shows "PASS", otherwise it will show "FAIL". Press any key to return to normal mode LCD display.</p>

KEY#	Description
19	<p>OPP key and LED Functions</p> <p>OPP test function Enable/Disable Key. Press the “OPP” key to enable the OPP test function and the indicator LED will be lit. The LCD display show “OPP” on right 5 left LCD display, shows “PRESS” on middle 5-digit LCD display and shows “START” on the lower 5-digit LCD display.</p> 
	<p>OPP test function parameter setting key. There are four parameters for the OPP test function. These parameters are: PSTAR, PSTEP, PSTOP and Vth. Press the “OPP” key again to set the OPP test parameter PSTAR (start power point). Press the “OPP” key again to proceed to the next parameter in order of PSTEP, PSTOP, Vth and Disable. Press any other key to exit and save the OPP setting. The OPP test parameter descriptions are as follows:</p>
	<p>a. PSTAR: setting the start power, The LCD display shows “OPP”, “PSTAR” and 0.00W (or initial setup value) from top to bottom 5 digits LCD display, the setting range is 0.00W to the full scale of the CP mode specification. The setting is by rotating the dial.</p> 

KEY#	Description
	<p>b. STEP: setting the increment step power, The LCD display shows “OPP”, “PSTEP” and 0.00W (or initial setup value) from top to bottom 5 digits LCD display, the setting range is 0.00W to the full scale of the CP mode specification. The setting is by rotating the dial.</p> 
	<p>c. PSTOP: setting the stop power, The LCD display shows “OPP”, “PSTOP” and 150.0W (or initial setup value) from top to bottom 5 digits LCD display, the setting range is 0.00W to the full scale of the CP mode specification. The setting is by rotating the dial.</p> 
	<p>d. Vth: Setting threshold voltage; The LCD display shows “OPP”, “Vth” and 0.00V (or initial setup value) from top to bottom 5 digits LCD display, the setting range is 0.00V to the full scale of the Voltage specification. The setting is by rotating the dial.</p> 
	<p>START/STOP Test key. Press START/STOP key to start or stop the OPP test when the OPP test function is enabled.</p> <p>The load will go to the “ON” state automatically when the “START/STOP” key is pressed and start the OPP test. The load will return to the “OFF” state automatically when the “START/STOP” key is pressed to stop the OPP test. The load will remain in the “ON” state if the load was “ON” before OPP test execution.</p> <p>The OPP test function tests the UUT’s over power protection function. The OPP test will start sinking current from PSTART and increase power by PSTEP until the UUT’s output voltage drops below the threshold voltage (V-th setting), and the OPP trip point is between the P_Hi and P_Lo limit settings. The lower 5- digits LCD display will shows "PASS", otherwise it will show "FAIL". Press any key to return to normal mode LCD display.</p>

KEY#	Description
20	<p>START/STOP key Operation</p>  <ol style="list-style-type: none"> Press START/STOP key to start or stop the short test by SHORT, OCP & OPP test setting parameter when SHORT, OCP & OPP test function is enabled. The load will go to "ON" automatically when pressing the "START/STOP" key to start the short test and the load will go to "OFF" automatically when pressing the "START/STOP" key to stop the short test. The load will stay to "ON" if it was "ON" before short test. The SHORT, OCP & OPP test functions are used to test the circuit protection of a unit under test. These tests will sink the load's maximum current or power to apply the test condition. If the UUT's voltage drop is between the V_Hi and V_Lo limits programmed, the lower 5-digit LCD display will show "PASS", otherwise it will show "FAIL". Press any key to return to normal mode LCD display.
21	<p>Rotary Shuttle Knob</p> <p>Right Knob: Adjust flash digit value clockwise to increase set value.</p>    <p>Right Knob: Adjust flash digit value counter-clockwise to increase set value.</p>    <p>Left Cursor key: Moves the flashing digit over to the left by one position.</p>    <p>Right Cursor key: Moves the flashing digit over to the right by one position.</p>    <p>Up Cursor key: Increments flashing digit setting value by one count.</p>   

KEY#	Description
	<p>Down Cursor key: Decrements flashing digit setting value by one count.</p> 
	<p>NOTE:</p> <ul style="list-style-type: none"> In CR MODE, the Right and Up Cursor keys decrease setting value. In CR MODE, the Left and Down Cursors keys increase setting value.
22	Load Input Banana Jack connectors. See section 5.6, "Load Connections" for details.
23	External voltage sense connectors. (V _{SENSE}). See section 7.5, "Voltage Sense Input Terminals" for details.
24	<p>DIM Key (LED)</p> <p>The DIM key enables or disables the PWM dimming signal output (26). When connected to the LED driver, turning OFF the DIM signal will cause the LED to be off and the DIM signal at zero. When ON, the LED will be on and the dimming signal will generate the programmed PWM signal.</p> <p>When DIM is ON, SETTING is OFF and the PWM frequency is set to DC, the voltage can be adjusted using the shuttle knob.</p> <p>When DIM is ON, SETTING is OFF and the PWM frequency is set from 100 to 1000Hz, the duty cycles can be adjusted using the shuttle knob.</p>
25	<p>SETTING Key (LED)</p> <p>The SETTING function controls the three PWM output signal parameters, LEVEL, FREQ and DUTY cycle .</p> <p>Press the dimming control SETTING key to sequence through these parameter settings:</p> <p>LEVEL ⇒ FREQ ⇒ DUTY ⇒ Exit</p> 
	<p>Set Dimming parameters as follows:</p> <ol style="list-style-type: none"> LEVEL setting: The lower LCD display shows the amplitude in volts. Available setting range is 0.00V to 10.00V. Step size is 0.04V. Adjust by rotating the shuttle knob.







KEY#	Description
	<p>b. FREQUENCY setting: The lower LCD display shows the PWM output frequency in Hz. Available setting range is DC or 100Hz to 1000Hz. Step size is 10Hz. Adjust by rotating the shuttle knob.</p> 
	<p>c. DUTY CYCLE setting: The lower LCD display shows the PWM output duty cycle. Available setting range is 0.01 through 0.99. Step size is 0.01. Adjust by rotating the shuttle knob.</p> 
	<p>The PWM dimming output signal is controlled by these three parameters as illustrated in the image below.</p>  <p>Level: 0V -10V Frequency = $1/T$ Duty Cycle = T_{Hi}/T DC: $T = T_{Hi}$</p>
26	<p>DIM Signal Output Terminals</p> 
27	<p>I-Monitor output BNC connector. See section 7.6, "Current Output Monitor (I-Monitor)" for details.</p> 
28	<p>Shorting Relay Signal Output Terminals</p> 

Table 6-1: Front Panel Display and Keyboard Functions

6.3 42D Series User Controls and Readouts

The following user controls, indicator and displays apply to 42D Series load modules only. The purpose and function of each control and indicator is cross-referenced to the equivalent keys on the 41D Series load modules. Refer to figure for the location of each control and indicator.




Figure 6-3: Front Panel User Controls and Indicators

The various controls and indicators are cross referenced to Table 6-1 of the previous section as the 42D controls are a sub-set of the 41D controls. Refer to the key number index shown in the right column of the table below.

KEY #	Equivalent 41D Module Key	Reference
1	1	Table 6-1
2	2	Table 6-1
3	3	Table 6-1
4	4	Table 6-1
5	5	Table 6-1
6	6	Table 6-1
7	7	Table 6-1
8	8	Table 6-1
9	9	Table 6-1
10	11	Table 6-1
11	13	Table 6-1
12	14	Table 6-1
13	16	Table 6-1
14	24	Table 6-1
15	25	Table 6-1

KEY #	Equivalent 41D Module Key	Reference
16	16	Table 6-1, (part of Config Menu on 41D)
17	-	Not required on 41D
18	17	Table 6-1
19	19	Table 6-1
20	20	Table 6-1
21	21	Table 6-1
22	22	Table 6-1
23	23	Table 6-1
24	26	Table 6-1
25	28	Table 6-1
26	-	Not included in Table 6-1

Table 6-2: Keyboard Layout Cross Reference between 42D and 41D LED Load Modules

6.4 Operating Flowchart for 41D+42D Series Load Modules

The flow chart on the next page shows the typical load current level and status setting procedures of each load module within a 44M0X mainframe. Load channel numbers 1 to 4 represent modules from left to right in the mainframe respectively. If the mainframe used has fewer than 4 slot positions, skip the corresponding module number.

- The strings shown in the square blocks are programming commands. Please follow the flow chart sequence for optimal and effective load settings.
- The load mode (CC, CR, CV, CP) should be set first. For CR and CV modes, only Static mode is available. For CC and CP modes, both Static and Dynamic modes are available.
- Next, choose high or Low load level and set the load levels for Static mode, or set the six parameters for Dynamic mode.
- The Limit key sets the GO/NG check upper and lower limits for DVM (voltage), DAM (current), and DWM (power) respectively.
- The system configuration settings for V-sense control, Load ON voltage, and load OFF voltage is part of the Limit setting.
- Other keys (Load ON/OFF, Short ON/OFF) can be controlled independently.




Figure 6-4: Operation Flow Chart - 41D+42D Series Load Module

6.5 Go/NoGo LIMIT Testing

The 41D+42D Series load modules have built in Go/NoGo test capability as part of their measurement systems. This allows abnormal conditions to be detected automatically so an EUT can be passed or rejected quickly in a production test environment.

6.5.1 Limits

The Go/NoGo is based on comparing measurement data against user provided upper and lower limit settings for voltage, current and power in the LIMIT system.

This creates a GO band (shown in green in the illustrations below) and a NoGo area. If the measurements fall inside the green zone, the test continues with the next step in an auto sequence. If not, a NoGo condition is flagged.

Go/NoGo has different implications depending on the operating mode selected. This is illustrated in the diagrams below.

6.5.2 Go/NoGo Testing in CC Mode

In constant current mode, the voltage limits are used to determine the pass or fail area for the input voltage.




Figure 6-5: LIMIT Test in CC Mode

6.5.3 Go/NoGo Testing in CC Dynamic Mode

In dynamic constant current mode, the voltage limits are used to determine the pass or fail area for the input voltage. **Note:** Applies to 41D Series LED load modules only.




Figure 6-6: LIMIT Test in Dynamic CC Mode

6.5.4 Go/NoGo Testing in CR Mode

In constant resistance mode, the voltage limits are used to determine the pass or fail area for the input voltage.




Figure 6-7: LIMIT Test in CR Mode

6.5.5 Go/NoGo Testing in CV Mode

In constant voltage mode, the current limits are used to determine the pass or fail area for the load current.




Figure 6-8: LIMIT Test in CV Mode

6.5.6 Go/NoGo Testing in CP Mode

In constant power mode, the current limits are used to determine the pass or fail area for the input voltage. **Note:** Applies to 41D Series LED load modules only.




Figure 6-9: LIMIT Test in CP Mode

6.6 Initial Power-on Settings

When powering up the 41D+42D Series electronic loads, the initial load settings are as shown in the tables below by model number. These are the factory default settings.

6.6.1 Model 41D3002 Initial Settings

Item		Initial value	Item		Initial value
CC L+Preset		0.000 A	LIMIT	V_Hi	300.000 V
CC H+Preset		0.000 A		V_Lo	0.000 V
CR H+Preset		125E3 Ω		I_Hi	2.000 A
CR L+Preset		125E3 Ω		I_Lo	0.000 A
CV H+Preset		300.000 V		W_Hi	150.00 W
CV L+Preset		300.000 V		W_Lo	0.00 W
CP L+Preset		0.000 W	CONFIG	SENSE	OFF
CP H+Preset		0.000 W		LD-ON	1.0 V
DYN	T HI	0.050 ms		LD-OFF	0.5 V
	T LO	0.050 ms		POLAR	+LOAD
	RISE	30.00 mA/ μ s		bW	Hi
	FALL	30.00 mA/ μ s		AVG	1
LED.No + Preset		1		Rd. DSP	Io
LED + Preset Vo		3.50 V	LED + Preset Vd		2.80 V
LED + Preset Io		0.2800 A	LED + Preset Rr		OFF
SHORT		Disabled	PWM SETTING	LEVEL	5.00 V
OPP		Disabled		FREQ	100 Hz
OCP		Disabled		DUTY	0.50

Table 6-3: Model 41D3002 Power-on Settings

6.6.2 Model 41D1020 Initial Settings

Item		Initial value	Item		Initial value
CC L+Preset		0.000 A	LIMIT	V_Hi	100.000 V
CC H+Preset		0.000 A		V_Lo	0.000 V
CR H+Preset		5000.0 Ω		I_Hi	20.000 A
CR L+Preset		5000.0 Ω		I_Lo	0.000 A
CV H+Preset		100.000 V		W_Hi	300.00 W
CV L+Preset		100.000 V		W_Lo	0.00 W
CP L+Preset		0.000 W	CONFIG	SENSE	OFF
CP H+Preset		0.000 W		LD-ON	1.0 V
DYN	T HI	0.050 ms		LD-OFF	0.5 V
	T LO	0.050 ms		POLAR	+LOAD
	RISE	300.0 mA/ μ s		bW	Hi
	FALL	300.0 mA/ μ s		AVG	1
LED.No + Preset		1		Rd. DSP	Io
LED + Preset Vo		3.50 V	LED + Preset Vd		2.80 V
LED + Preset Io		0.700 A	LED + Preset Rr		OFF
SHORT		Disabled	PWM SETTING	LEVEL	5.00 V
OPP		Disabled		FREQ	100 Hz
OCP		Disabled		DUTY	0.50

Table 6-4: Model 41D1020 Power-on Settings

6.6.3 Model 41D5002 Initial Settings

Item		Initial value	Item		Initial value
CC L+Preset		0.000 A	LIMIT	V_Hi	500.000 V
CC H+Preset		0.000 A		V_Lo	0.000 V
CR H+Preset		250E3 Ω		I_Hi	2.0000 A
CR L+Preset		250E3 Ω		I_Lo	0.000 A
CV H+Preset		500.000 V		W_Hi	300.00 W
CV L+Preset		500.000 V		W_Lo	0.00 W
CP L+Preset		0.000 W	CONFIG	SENSE	OFF
CP H+Preset		0.000 W		LD-ON	5.0 V
DYN	T HI	0.050 ms		LD-OFF	0.0 V
	T LO	0.050 ms		POLAR	+LOAD
	RISE	30.0 mA/ μ s		bW	Hi
	FALL	30.0 mA/ μ s		AVG	1
LED.No + Preset		1		Rd. DSP	Io
LED + Preset Vo		17.50 V	LED + Preset Vd		14.00 V
LED + Preset Io		0.3500 A	LED + Preset Rr		OFF
SHORT		Disabled	PWM SETTING	LEVEL	5.00 V
OPP		Disabled		FREQ	100 Hz
OCP		Disabled		DUTY	0.50

Table 6-5: Model 41D5002 Power-on Settings

6.6.4 Model 42D5003 Initial Settings

Item		Initial value	Item		Initial value
CC L+Preset		0.000 A	LIMIT	V_Hi	500.000 V
CC H+Preset		N/A		V_Lo	0.000 V
CR H+Preset		10E3 Ω		I_Hi	2.4000 A
CR L+Preset		N/A		I_Lo	0.000 A
CV H+Preset		500.000 V		W_Hi	120.00 W
CV L+Preset		N/A		W_Lo	0.00 W
CP L+Preset		0.000 W	CONFIG	SENSE	OFF
CP H+Preset		N/A		LD-ON	5.0 V
DYN	T HI	N/A		LD-OFF	2.5 V
	T LO	N/A		POLAR	+LOAD
	RISE	N/A		bW	Hi
	FALL	N/A		AVG	1
LED.No + Preset		1		Rd. DSP	Io
LED + Preset Vo		17.50 V	LED + Preset Vd		14.00 V
LED + Preset Io		0.3500 A	LED + Preset Rr		OFF
SHORT		Disabled	PWM SETTING	LEVEL	5.00 V
OPP		Disabled		FREQ	100 Hz
OCP		N/A		DUTY	0.50

Table 6-6: Model 42D5003 Power-on Settings

7 Load Connections, Applications and Protection Features

This section covers the following topics:

- Available connectors on the 41D+42D Series load modules
- Connecting the load to various types of equipment
- Internal and External Voltage Sense
- Protection features

7.1 INPUT Terminals

The positive and negative terminals for load input connection are located on the lower front panel of the load module.

Note: Always refer to Section 2.3 “Safety Information” and Section 2.4 “Safety Notices” before making any load connections.

7.1.1 Banana Jack Connectors

This is the most common way for connecting the equipment to be tested with a 41D+42D Series load. It is recommended that this connector be used when the load current is less than 20A as the maximum rated current of the plug connector is 20A. Please avoid exceeding maximum rated current to prevent damage caused by overheating. The maximum supported wire gauge for this connection method is AWG #14.

7.1.2 Y-hook / Spade Lug Terminals

Included in the 41D+42D Series load module ship kit is a set of two (2) spade lug-type terminals. These can be used to crimp on to stripped wire ends of an EUT. Hook-type terminals provide good contacting characteristics. It is recommended that the hook-type terminal be used for any occasion where practical. The maximum supported wire gauge of the connection wires for this connection method is AWG #10.

7.1.3 Lead Wire Insertion

This is the simplest way to insert stripped ends of connecting wires into the holes on the metal portion of the input connector jacks. The maximum supported gauge of the connecting wire for this connection method is AWG #14.

7.1.4 Banana Jack Connector and Spade Lug Terminals

This combination method provides a higher current rating and lower impedance of the load connection. When input load currents are higher than 20A or the connecting lead wire is long, this method will be optimal.

7.1.5 Plug Connector and Lead Wire Insertion

This method can also be used when the input current is higher than 20A or the connecting lead wire is longer.

7.2 Wire Size

A major consideration in making input connection is the wire size. The minimum wire size is required to prevent overheating and to maintain good regulation. It is recommended that the wires are sized large enough to limit the voltage drop at the maximum current rating of the DC load to less than 0.5V per lead.

If needed, wire size can be increased by doubling the number of wires using two space lugs per side as shown in Figure 7-1.

7.2.1 Wire Size Guidelines

The following table provides a guide to the current carrying capability (ampacity) of Metric and AWG wire sizes. Metric sizes are expressed as a cross sectional area (CSA) in square millimeters. If in doubt regarding the rating of a cable or wire, consult your cable supplier.





Figure 7-1: Doubling wire size using spade lugs

Ampacity	AWG Size	CSA (mm ²)	Notes
5.0	22	-	Ampacity of aluminum wire is approx. 80% of copper rating
8.33	20	-	
10	-	0.75	When two or more wires are bundled together, ampacity for each wire must be reduced to the following %:
15.4	18	-	
13.5	-	1	
	16	-	2 conductors 94%
16	-	1.5	3 conductors 89%
31.2	14	-	4 conductors 83%
25	-	2.5	5 conductors 76%
40	12	-	
32	-	4	Maximum temperatures:
55	10	-	Ambient: 50°C / 122°F
40	-	6	Conductor: 105°C / 221°F
75	8	-	
63	-	10	
100	6	-	
135	4	-	

Table 7-1: Load Wire Size Table

Notes: AWG ratings are based on MIL-W-5088B, Metric size ratings are based on IEC Publications.

7.3 Connecting a UUT


WARNING

DO NOT EXCEED LOAD INPUT VOLTAGE RATING

This instrument does **NOT** have a means to disconnect its Load input from a connected power supply. If the voltage applied to the Load input exceeds its maximum rating – even if the load is turned completely off – damage to the load **WILL** occur. Damage caused by exceeded maximum load input voltage under any circumstance is **NOT** covered by the manufacturer’s product warranty. Remove any load input connections when the load is not in use, even when it is turned off.

When setting up for a new test and connecting any equipment to the DC load, proceed as follows:

1. Always make sure the DC load is turned OFF at the POWER switch when making any wire connections.
2. Check that the output of the equipment under test is **OFF**.
Note: Some power equipment’s output may still be energized even if the equipment has been turned off or its output is turned off. This is especially true for DC power supplies.

Note: When working with batteries, it is recommended to provide a suitable disconnect relay or switch so the load connection can be disconnected from the battery for handling purposes.

3. Connect one end of the load wires to the load input terminals on the rear panel.
4. Check the polarity of the connections and connect the other end of the load wires to the output terminal of the equipment under test.
5. When connecting multiple loads to the same EUT, makes sure the load wire lengths to each load are the same.

7.4 Polarity and Ground – Multiple Output Power Supplies

- It is recommended to connect the negative DC terminal to ground for positive output power supply EUTs.
- It is recommended to connect the positive DC terminal to ground for negative output power supply EUTs.
- When connecting multiple output DC power supplies, at all times, the potential of the positive DC load module input (Red binding post) **MUST** be at a higher potential than that of the negative DC load module input (Black binding post). Refer to the example show in Figure 7-2.




Table 7-2: Multiple Output DC Supply Polarity Connection

7.5 Voltage Sense Input Terminals

When the voltage sense mode is set to internal (local), the DC load module senses the DC at the input terminals of the DC load. Any voltage drop between the EUT and the load module across the load wires is not detected so the actual voltage at the EUT may be somewhat higher than is sensed by the load. For low current applications, the voltage drop may be negligible. Figure 7-2 shows the load connection with internal sense mode.



Figure 7-2: DC Load Connection with Internal Voltage Sense

To measure the UUT output DC voltage directly at the UUT terminals, external (remote) voltage sense mode must be used. The external voltage sense terminals are provided on the front panel of the load module for this purpose. Refer to Figure 7-3 for details on the V Sense terminal location and polarity. This mode is recommended for higher current applications and situations where the load wires are long and voltage precision is important.

Load leads should be bundled or tie wrapped together to minimize inductance.




Figure 7-3: DC Load Connection with External Voltage Sense

7.6 Current Output Monitor (I-Monitor)

The I-Monitor terminal is designed to monitor the electronic load's input current or short current. An isolated amplifier output with 0V to 10V full scale output signal represents the zero to full scale current the electronic load is sinking.

Please refer to the I-Monitor voltage /current scaling values for each 41D+42D Series load module in Section 4, "Technical Specifications".

7.6.1 Non-Isolated Output

The I-Monitor output can be used to display and capture the load current waveform on a digital storage oscilloscope to further evaluate the voltage and current waveform of a power supply under test.

Note: The I-Monitor is **non-isolated**. It is intended to support power supply development and testing and must be ground referenced.

To allow monitoring of both voltage and current simultaneously on a dual channel oscilloscope, care must be taken not to create ground loops. Most oscilloscope inputs are ground referenced and input channels are **not** isolated from each other.



CAUTION

The 41D+42D Series Current Output Monitor or I-Monitor is NOT ISOLATED. Do NOT use the I-Monitor output with different channels to avoid common grounding problems. Improper connections may cause damage

7.6.2 Output Impedance

The I-Monitor output volt range is 0 to 10V. Output impedance is 1K Ω . The equivalent output circuit of the I-Monitor output is shown in the figure below.




Figure 7-4: Equivalent I-Monitor Output Circuit

7.6.3 Connecting I-Monitor Output to an Oscilloscope

When you connect the load's current monitor to an oscilloscope, please carefully check the polarities of the scope probes of the oscilloscope as shown in Figure 7-3.




Figure 7-5: Correct I-Monitor Connections to UUT and Oscilloscope

Reversing signal and ground on the voltage probe will result in a current to flow to ground as shown in Figure 7-4 and may damage the UUT, the oscilloscope and possibly the electronic load.




Figure 7-6: **Incorrect** I-Monitor Connections to UUT and Oscilloscope

7.7 Parallel Operation

It is possible to operate load modules in parallel if the power and/or current capability of a single load module is not sufficient.

7.7.1 Parallel Mode Connection

The positive and negative outputs of the power supply must be connected individually to each load module's input as shown in Figure 7-7 below. The setting is made at each individual load module. The total load current is the sum of the load currents being taken by each module.




Figure 7-7: Parallel Load Connection

7.7.2 Allowable Operating Modes

It is permitted to operate 4 series load modules with different voltage, current and power ratings to sink in parallel. For example the loads modules shown in Figure 7-7 could be a mixture of 41L0660, 41L0630, 42L0824, and 41D1020.

While in static mode, the load modules can be set to operate in CC, CR or CP mode.

7.7.3 Exceptions

1. Parallel operation in DYNAMIC mode is not allowed.
2. Parallel operation in CV mode is not possible.



7.8 Series Operation

Series operation of dc load modules to achieve higher voltage ranges than supported by an individual load module is **NOT** allowed under any circumstance.



7.9 Zero-Voltage Loading

As shown in Figure 7-8, the Electronic load can be connected in series with a DC voltage source (DC power supply in CV mode) with an output voltage greater than:

- 0.7Vdc (41D3002)
- 6.0Vdc (41D1020, 41D5002, 42D5003)

This allows the device under test connected to the electronic load to be operated down to a zero volt condition. The external DC voltage source provides the minimum operating voltage required by the electronic load. This application is suitable for low voltage battery cell high discharge current testing.




Figure 7-8: Zero Volt Load Connection


7.10 Protection Features

The 41D+42D Series electronic loads include the following protection features:

- Over Voltage
- Over Current
- Over Power
- Over Temperature
- Reverse Polarity Indication

7.10.1 Over Voltage Protection

The over voltage protection circuit is set at a predetermined voltage depending on the load model and **cannot** be changed. If the over voltage circuit has tripped, the load input turns OFF immediately to prevent damaging the load. When an over voltage trip condition has occurred, the digital current meter's LCD display will indicate "OVP"



7.10.2 Over Current Protection

The load always monitors the current it is sinking. When the current sink is greater than 105% of the rated maximum current, the load module will turn load to OFF state internally. When an over current condition has occurred, the digital current meter's LCD display will indicate "OCP".

7.10.3 Over Power Protection

The load always monitors the power dissipated by the load. When the power dissipation is greater than 105% of the rated power input, the load module will turn load to OFF state internally. When an over power condition has occurred, the digital current meter's LCD display will indicate "OPP".

7.10.4 Over Temperature Protection

As soon as the temperature of load's internal heat sinks reaches a level greater than 90° C (194° F), the over temperature protection is triggered. The digital current meter's LCD display will indicate "OTP". The load will turn to the OFF state internally.

Please check environmental conditions such as the ambient temperature and distance between the rear panel of the load chassis and any wall is greater than 15cm / 6 inches.

The load can reset the Over Voltage, Over Current, Overpower and Over Temperature protection if the condition that caused the fault is removed and the "LOAD" key is pressed to set "ON" state.

7.10.5 Reverse Polarity Protection Indication

The 41D+42D Series electronic load conducts reverse current when the polarity of the DC source connection is incorrect. The maximum reverse current is a function of the load model. If the reverse current exceeds the maximum reverse current, it may damage the load.

When a reverse polarity current condition exists, the reverse current is displayed on the 5 digit current meter on the front panel, and the 5-digit DVM indicates a **negative** current reading. Whenever a reverse current is displayed on the current meter, turn OFF power to the DC source immediately and make the correct connections.

8 Mod Application Examples

8.1 Overview

Given the wide variety of led types, brands, ratings and multiple ways to cascade, series and or parallel LED's, testing LED drivers or power supplies for this wide range of configurations and test conditions can be very costly if actual LED's are used. Furthermore, high brightness LED's can damage a user's vision when exposed to high intensity light for any period of time.

When using a programmable DC load like the 41D or 42D series, these problems are eliminated.

8.2 LED Characteristics

The electrical equivalent of a light emitting diode (LED) is shown in the center of the figure below. It consists of an forward resistance (R_d) in series with a forward voltage source (V_d). The current through the diode in the forward direction will change exponentially with the applied voltage (V_o) across it.




Figure 8-1: LED Equivalent Circuit Diagram

Conduction of current does not start until $V_o > V_d$. At this point, the LED current is:

$$I_o = \frac{(V_o - V_d)}{R_d}$$

8.2.1 Definitions

The following electrical LED parameter definitions will be used in the remainder of this section:

V_d = LED forward voltage

R_d = LED forward resistance

V_o = Voltage across LED

I_o = LED forward current

8.2.2 LED Operation

If the LED driver supply is a constant current source, we know from our previous formula that the voltage V_o across the LED will be:

$$V_o = V_d + (I_o * R_d)$$

Note that most LEDs have a negative temperature coefficient (NTC) of about 2mV to 4mV per degree C caused the forward voltage V_d to drop as the LED warms up. This in turn will result in V_o dropping as well as the LED gets warm until the temperature of the LED stabilizes.

Figure 8-2 shows the V_o voltage and I_o current waveforms of an LED when driven by a constant current type LED driver. Notice the current ripple caused by the LED driver which also results in a DC voltage ripple across the LED. Typically, this ripple has a triangular wave shape and is at the switching frequency of the LED driver PWM circuit.




Figure 8-2: LED Voltage and Current Waveforms

8.3 Multiple LED Configurations

For most lighting applications, more than one LED is used to obtain desired light output in lumens. These configurations can be series, parallel or any combination thereof. Each configuration impacts the setting of the 41D or 42D programmable load differently. This section examines various possible configurations and how to set up the load to simulate them.

8.3.1 Series or Cascading Mode

Series connection of two or more LEDs to obtain higher brightness is a common approach. This configuration also allows a higher voltage and lower current supply to be used to provide the necessary power to the LEDs. With a series configuration, the V_d and R_d values for each LED sum together. The figure below shows an example of three LEDs in series and the equivalent electrical circuit with V_{dx3} and R_{dx3} . The V-I exponential curve for the combination of LEDs is shown in this case. Load settings should be based on the V_{dx3} and R_{dx3} values rather than the individual LED values.




Figure 8-3: Series or Cascading LED Configuration

There are some drawbacks of a series string of LEDs that limit the number of LEDs that can be contained in a single string.

1. As the number of LEDs increases, the total voltage across the string will get high. At some point, this results in potential voltage breakdown and safety risks. Most LED drivers are limited to about 500Vdc max for this reason.
2. If any one of the LEDs in the series string fails, the entire string will turn off. This represents a single point of failure and negatively impacts reliability and durability of the light fixture.

8.3.2 Parallel Mode

To overcome some of the drawbacks of series LED strings listed in the previous paragraph, a combination of two or more series strings can be connected in a parallel configuration. This prevents the total voltage from ever increasing and also improves reliability as any one series string can fail without losing all light output.

The figure below illustrates an example where two series strings of LEDs with three LEDs each are connected in parallel. Despite using six LEDs total, the V_o is limited to V_{dx3} as in the series example before. However, there is twice the light output and redundancy. However, the R_d of the series/parallel combination is only half that of the series examples as we now have two R_{dx3} value strings in parallel. The V-I exponential curve for the series/parallel combination of LEDs is shown in this case. Load settings should be based on the V_{dx3} and $R_{dx3}/2$ values rather than the individual LED values.




Figure 8-4: Parallel LED String Configuration

Now that we know the various possible LED string configurations, it will be easier to set the 41D or 42D load module for the application at hand.

8.4 LED Mode Settings

In LED mode of operation, the DC load provides the following LED specific setup parameters:

- No.
- V_d
- R_d
- V_o
- I_o
- R_r

Appropriate setting values for these parameters by LED manufacturer and part number or type should be available from the LED manufacturer. If not, an approximation can be used or these values can be established experimentally.

8.4.1 LED No. Setting

The LED No. setting simulates the number of cascaded LEDs in a serial string. Setting range is from 1 to 90 for models 41D3002, 41D5002 and 42D5003 and from 1 to 3 for model 41D1002.

NOTE: Changing the quantity of LEDs may result in a possible shift in the value of R_d . R_d automatically switches back to its original setting if you have exceeded the value of the nearest range. After changing the quantity No. value, confirm V_d to see if all settings are correct.

8.4.2 LED V_d Setting

LED forward voltage drop. This value depends largely on the LED type. Typical values by LED type are shown in the table below.

Substrate material	Description	Typical V_d Value
GaAs	Gallium Arsenide	1.0 V
GaAsP	Gallium arsenide phosphide	1.2 V
GaP	Gallium phosphide	1.8 V
GaN	Gallium nitride	2.5 V

Figure 8-5: Typical LED V_d Values by LED Type

If no LED specification data is available, try using the LED driver specifications to estimate the appropriate V_d . If the LED driver has a maximum output voltage of V_o , the V_d and be estimated at about 70 to 90% of V_o . An initial value of 80% is a good starting point.

8.4.3 LED R_d Setting

This information should be available on the LED datasheet. If no LED specification data is available, try using the V_d value of the LED and the LED driver specifications to estimate the appropriate R_d . If the LED driver has a maximum output voltage of V_o and a maximum rated output current of I_o , the R_d and be estimated by using the following formula:

$$R_d = \frac{V_o - V_d}{I_o}$$

8.4.4 Impact of Changing V_d and R_d on Voltage and Current

Setting the V_d and R_d values will determine how the load behaves when voltage/current is applied. The basic V-I load curve will be determined by these two parameters and the input current to the load from the LED driver. This chart is shown in Figure 8-6.




Figure 8-6: LED V_d and R_d Based Load Curve

Changing one or both LED parameter affects this curve as illustrated in Figure 8-7.




Figure 8-7: LED Based Load Curve Effects

8.4.5 LED V_o Setting

Since most LED driver supplies are current source, the DC load used a constant voltage mode (CV) to simulate the LED load. The voltage set value is V_o . This set value is based on the LED driver specification.

8.4.6 LED I_o Setting

This value is related to the other LED parameters as follows:

$$I_o = \frac{(V_o - V_d)}{R_d}$$

8.4.7 LED Rr Settings

Although the LED won't turn on until the voltage across it exceeds V_d , some leakage current may be flowing at these lower voltages ($V_o < V_d$). The electrical circuit of the LED can be enhanced by adding a relative high value parallel impedance to the original LED circuit model. This leakage current can be simulated by setting the R_r value on the 41D or 42D load. The R_r represents the LED resistance below the forward bias voltage is reached. This more closely simulates the load characteristics on an LED as illustrated in Figure 8-8.




Figure 8-8: Enhanced LED V-I Curve Model

The R_r value impacts the R_d value as follows:

$$R_d = \frac{V_o - V_d}{I_o - V_o/R_r}$$

The R_r parameter can also be used to increase or decrease the current ripple size.

9 Auto Sequence Programming Examples

9.1 Overview

An auto-sequence allows the user to step through previously saved set-ups stored in the mainframe's memory. Up to nine auto-sequences can be saved. Each auto-sequence can consist of up to sixteen steps. There are two modes available for the auto-sequence function. These are **edit mode** - to set up an auto-sequence and **test mode** - to recall and start an auto-sequence execution.

9.2 Edit Mode

To set up a new auto-sequence using the Edit mode, proceed as follows:

1. Set-up all load parameters such as the operating mode, along with sink values and the LOAD ON/OFF status. Configuration and limit settings can also be set and the NG ON function may be selected as part of the setup.
2. Press the STORE key and one of the numbered STATE keys to store the set up in one of the memory locations. The BANK number can also be changed to provide additional memory locations.
3. Repeat the previous steps as needed to create additional load set-ups and saved them to separate memory locations using the STORE, BANK and STATE keys.
4. Once the required number of load setups has been saved enter the EDIT mode by pressing the EDIT key. The EDIT key will light up indicating the EDIT mode is active.
5. With the EDIT button lit, the auto-sequence identity (F1 to F9) can be selected using the numbered STATE keys.
6. Now select the first memory location by pressing the up/down arrow keys to select the BANK and STATE. This will become the first step of the AUTO-SEQUENCE.
7. Press ENTER to set the chosen BANK and STATE memory location.
8. Using the arrow keys set the test time (T1) and NG/LIMIT checking time (T2) for that step of the auto-sequence.
9. Press ENTER to save the time setting and move onto the next step of the auto-sequence.
10. Repeat steps 6 to 9 to as needed to enter up to 16 steps to form the auto-sequence.
11. Once the desired number of steps have been set, press the STORE button.
12. The LCD will show REP (repetitions).
13. Use the arrow keys to set the number of auto-sequence repetitions.
14. Press STORE to confirm the sequence edit.

This completes the programming sequence.

9.3 Test Mode

To execute a previously stored auto-test sequence, proceed as follows:

1. Press the TEST key on the mainframe to enter the TEST mode.
2. Use the numbered STATE keys (1 to 9) to select the previously saved auto-sequence.
3. Press ENTER to start the auto-sequence.
4. The LCD shows "PASS" or "FAIL" after testing.
If limits and the NG functions have been set and a test step fails, the mainframe LCD display will flash "NG". The user must then press ENTER to continue the auto-sequence execution or EXIT to abort the auto-sequence.
5. Press auto-sequence or EXIT at any time to abort an auto-test sequence.

9.4 AUTO TEST SEQUENCE Example

In this example, we will create a program based on following illustration of a varying current over time. A total of eight sequence steps will be needed to implement this sequence. The program executes steps 1 to 8 in sequence.




Figure 9-1: Auto-Test Sequence Example Illustration

The desired current levels and durations are shown in the table below.


Auto-sequence Step number	Memory BANK	Memory STATE	Current Value	Execution Time (T1+T2)
1	3	1	1.0 Adc	200 ms
2	3	2	5.0 Adc	200 ms
3	3	3	1.0 Adc	400 ms
4	3	4	5.0 Adc	400 ms
5	3	5	1.0 Adc	200 ms
6	3	6	10.0 Adc	1000 ms
7	3	7	1.0 Adc	1000 ms
8	3	8	0.0 Adc	1000 ms

Table 9-1: Auto-Test Sequence Example Values

To program this sample sequence, proceed as follows:

1. Set the operation mode: Press the mode key to CC mode.
2. Set the range: Press RANGE key to force range 2.
3. Set LOAD ON/OFF Status: Press load ON.
4. Set the current values steps 1-8 and store to memory BANK 3 STATES 1-8.
5. Press EDIT key.
6. Press the number 2 key to select F2 as the auto sequence location.
7. Press up/down key to memory bank 3 and state 1.
8. Press ENTER key to confirm the sequence memory.
9. Press up/down key to set the test time for that step (T1+ T2).
10. Press ENTER key to confirm the sequence step.
11. Repeat steps 7 to 10 to set auto-sequence steps 1-8.
12. After setting the final step, press the STORE key.
13. Press up/down key to 1 to repeat the auto-sequence one time.
14. Press STORE key to confirm the number of repetitions.
15. Press TEST key to enter TEST mode.
16. Press number 2 to select auto-sequence F2.
17. Press ENTER to confirm selection and start TEST.
18. The load will now step through the auto-sequence.

The current test waveform can be checked on an oscilloscope as shown below - assuming that the DC source can supply the programmed load currents.



10 Short Circuit, OPP and OCP Test Examples

10.1 Overview

This appendix provides examples on how to program the built-in test modes of the 5 Series loads. These tests allow commonly used functional testing of power supplies with minimal programming effort.




Figure 10-1: Built-in Test Modes - Flow Chart OCP, OPP, SHORRT

The parameters for the Short, Over Power Protection and Over Current Protection tests can all be programmed over the optional computer interfaces. The following examples may prove useful.

10.2 SHORT Test

To invoke short circuit testing of a unit under test, send the following sequence of commands to the load:

SHORT Test

This example sets a short test for 500ms until the STOP command is received.


REMOTE	Set Remote
TCONFIG SHORT	Set SHORT test function
STIME 500	Sets short time to 500ms time*
START	Start SHORT testing
TESTING?	Ask Testing? 1:Testing, 0:Testing End
STOP	Stop SHORT testing

* if 500 is replaced with 0 the short test is continuous until STOP command

10.2.1 External SHORT RELAY Based Test

The SHORT test applies the maximum current supported by the load module to the EUT. For LED drivers, this is not always a sufficiently severe short circuit test. For situations where a dead-short is required to test the EUT, an external 12V shorting relay can be controlled by the 41D/42D Short output driver signal.

This output is available on the front panel of the load module directly below the PWM signal output terminals.



This test setup is shown in Figure 10-1 below.




Figure 10-2: External SHORT Relay Test Setup

10.2.2 SHORT Relay Test Procedure


The external shorting relay may be used in combination with the SHORT test but the voltage high threshold must be set close to zero as the dead short created by the relay will cause the voltage to collapse.

Connect the shorting relay as shown in Figure 10-1 above.

Press the SHORT key to enter the SHORT test mode.



Press the SHORT key again to display the TIME screen. Press UP cursor key or turn the shuttle to select 10000 msec.



Press the SHORT key again to display the V_HI screen. Press DOWN cursor key or turn the shuttle to set 1.00 V.



Press the SHORT key again to display the V_Lo screen. Press DOWN cursor key or turn the shuttle to set 0.00 V.



Press START/STOP key to start the short test. The relay should engage shorting the load input terminals.



If the input voltage drops below 1.0V, the results will show PASS when the 10 second test interval is completed. If not, the result will be FAIL.



10.2.3 Remote SHORT Programming Commands

Short circuit testing can be performed over the bus if needed using the following command sequence. Refer to the 44M0X mainframe manual for more detailed programming information.

REMOTE	(Set Remote)
TCONFIG SHORT	(Set SHORT test)
STIME 1	(Set short time 1ms)
START	(Start SHORT testing)
TESTING?	(Ask Testing? 1 : Testing , 0 : Testing End)
STOP	(Stop SHORT testing)

10.3 OPP Test

To invoke over power protection circuit testing of a unit under test, send the following sequence of commands to the load:

OPP Test

In this example, threshold limits are set and the NG signal is enabled.

REMOTE	Set Remote
TCONFIG OPP	Set OCP test
OPP:START 3	Set start load watt 3W
OPP:STEP 1	Set step load watt 1W
OPP:STOP 5	Set stop load watt 5W
VTH 0.6	Set OPP VTH 0.6V
WL 0	Set watt low limit 0W
WH 5	Set watt high limit 5W
NGENABLE ON	Set NG Enable ON
START	Start OPP testing
TESTING?	Ask Testing? 1:Testing, 0:Testing End
NG?	Ask PASS/FAIL? 0:PASS,1:FAIL
OPP?	Ask OPP watt value
STOP	Stop OPP testing

10.4 OCP Test

To invoke over current protection circuit testing of a unit under test, send the following sequence of commands to the load:

OCP Test

This test will start sinking current at 3A and increase to 5A in 1A steps.

REMOTE	Set Remote
TCONFIG OCP	Set OCP test
OCP:START 3	Set start load current 3A
OCP:STEP 1	Set step load current 1A
OCP:STOP 5	Set stop load current 5A
VTH 0.6	Set OCP VTH 0.6V
IL 0	Set current low limit 0A
IH 5	Set current high limit 5A
NGENABLE ON	Set NG Enable ON
START	Start OCP testing
TESTING?	Ask Testing? 1:Testing, 0:Testing End
NG?	Ask PASS/FAIL?,0:PASS,1:FAIL
OCP?	Ask OCP current value
STOP	Stop OCP testing.

Note: This mode is only available on 41D Series LED Modules. Not supported on the the dual channels 42D Series loads.

11 Remote Control Programming

11.1 Overview

Program command syntax for all 4 Series load modules is contained in the 44M0X mainframe operation manuals. Refer to any of the 44M01, 44M02 or 44M04 operating manuals for the 4 Series mainframe:

Mainframe model 44M01: P/N 160901-10

Mainframe model 44M02: P/N 160902-10

Mainframe model 44M04: P/N 160904-10

12 Calibration

12.1 Overview

All APS products ship with factory calibration. No additional calibration is required when first received.

12.2 Calibration Interval

The recommended calibration interval for these loads is one year (12 months). Routine annual calibration can be performed by most calibration labs that have low frequency measurement and power calibration capabilities. Alternatively, the load can be returned to the manufacturer to obtain a factory calibration.

12.3 Calibration Coefficients

The 44M04 mainframe requires no calibration but the 41L, 42L, 41D and 42D load modules do. All calibration is performed through software. No manual internal adjustments have to be made as part of routine calibration.

Calibration coefficients for the following parameters and functions are stored in non-volatile memory:

Parameters	Coefficients Stored
Load Current	All modes, DC, Offset and Gain, High Range & Low Range
Resistance	All modes, DC, Offset and Gain, High Range & Low Range
Voltage Measurement	DC, Offset and Gain
Current Measurement	DC, Offset and Gain
Power Measurement	DC, Offset and Gain

12.4 Calibration Procedures

Certified calibration labs may request a copy of the calibration manual for the relevant load model by contacting the nearest Adaptive Power Systems company location. Refer to Section 1, "Contact Information".

13 CE MARK Declaration of Conformity

Directive: 2004/108/EC

Product Name 41D+42D Series, 42L Series, 41D Series, 42D Series DC Electronic Loads

Serial Number _____

The manufacturer hereby declares that the products are in conformity with the following standards or other normative documents:

SAFETY:

Standard applied IEC 61010-1:2001

EMC:

Standard applied EN 61326-1:2006

Reference Basic Standards:

EMISSIONS:

CISPR11: 2003+A1: 2004+A2: 2006
EN 61000-3-2: 2006
EN 61000-3-3: 2008

IMMUNITY:

IEC 61000-4-2: 2008
IEC 61000-4-3: 2008
IEC 61000-4-4: 2004 +Corr.1: 2006 +Corr.2: 2007
IEC 61000-4-5: 2005
IEC 61000-4-6: 2003+A1: 2004+A2: 2006
IEC 61000-4-8: 2001
IEC 61000-4-11: 2004

Supplemental Information:

When and Where Issued: March 28, 2014
Irvine, California, USA

Authorized Signatory

Loc Tran
Quality Assurance Inspector
Adaptive Power Systems

Responsible Person

Joe Abranko
Adaptive Power Systems
17711 Fitch
Irvine, California, 92649, USA



Mark of Compliance

14 RoHS Material Content Declaration

The table below shows where these substances may be found in the supply chain of APS's products, as of the date of sale of the relevant product. Note that some of the component types listed above may or may not be a part of the enclosed product.

Part Name	Hazardous Substance					
	<i>Pb</i>	<i>Hg</i>	<i>Cd</i>	<i>Cr6+</i>	<i>PBB</i>	<i>PBDE</i>
PCB Assy's	x	0	x	0	0	0
Electrical Parts not on PCB Assy's	x	0	x	0	0	0
Metal Parts	0	0	0	x	0	0
Plastic Parts	0	0	0	0	x	x
Wiring	x	0	0	0	0	0
Packaging	x	0	0	0	0	0

Legend:

0: Indicates that the concentration of the hazardous substance in all homogeneous materials in the parts is below the relevant RoHS threshold.

x: Indicates that the concentration of the hazardous substance of at least one of all homogeneous materials in the parts is above the relevant RoHS threshold.

Notes:

1. APS has not fully transitioned to lead-free solder assembly at this point in time. However, the vast majority of components used in production are RoHS compliant.
2. These APS products are labeled with an environmental-friendly usage period in years. The marked period is assumed under the operating environment specified in the product specifications.

Example of marking for a 10 year period.



Index

A

AC Input	26
Accessories	21

C

Configuration	40, 66, 93
Connections	35, 74, 81
Constant Current ..13, 14, 16, 24, 37, 38, 40, 41, 43, 44, 45, 55, 59, 60, 68, 69, 70, 72, 73, 82, 96	
Constant Power13, 15, 24, 37, 40, 41, 43, 44, 45, 55, 61, 62, 68, 71, 72, 73, 82	
Constant Resistance....13, 14, 24, 40, 41, 43, 44, 45, 55, 64, 68, 70, 72, 73, 82	
Constant Voltage ..13, 14, 24, 40, 41, 43, 44, 45, 55, 68, 71, 72, 73, 82, 83	
Contact	8, 34, 104
Contents	3
Cooling.....	26

D

Display	42, 43, 65
Dynamic mode.....	44, 52, 68

F

Features	20, 74, 84
Frequency	17
Front panel operation	41

G

Go/NoGo.....	40, 48, 66, 69, 70, 71
--------------	------------------------

I

Installation	9, 22, 32, 33
--------------------	---------------

L

LED	44, 45, 48, 51, 52, 54, 57, 59, 61
LED Applications.....	86
LED Mode	15
Level	45

O

OCP test.....	42, 43, 59, 60, 101, 102
OPP test.....	42, 43, 61, 62, 63, 101

P

Parallel operation	82
Programming.....	36, 39, 93, 103
Protection.....	25, 40, 66, 74, 84, 85, 97

S

Series operation	82
Short test.....	42, 43, 57, 58
Size	75
Slew rate	17
Specifications	24, 38, 79

T

Terminals.....	74, 78
Turn on	34

W

Warranty	9
Waveform	17
Weight.....	26



ADAPTIVE Power Systems

Worldwide Supplier of Power Equipment

Copyright © 2014, Adaptive Power Systems, Inc. (APS) • All Rights Reserved • No reproduction without written authorization from APS.